

TRIBER

vehicle user manual



Welcome aboard your vehicle

This vehicle user manual contains the information necessary:

- for you to familiarise yourself with your vehicle, to use it to its best advantage and to benefit fully from all the functions and the technical developments it incorporates.
- to ensure that it always gives the best performance by following the simple, but comprehensive advice concerning regular maintenance.
- to enable you to deal quickly with minor faults not requiring specialist attention.

It is well worth taking a few minutes to read this manual to familiarise yourself with the information and guidelines it contains about the vehicle and its functions and new features. If certain points are still unclear, our authorised dealers will be pleased to provide you with any additional information.

The following symbol will help you when reading this manual.



These appear in the vehicle and indicate that you should consult the manual for detailed information and/or limits on operations with respect to your vehicle's equipment.

→ anywhere in the manual indicates a transfer to a page.



anywhere in the manual indicates a hazard, danger or a safety recommendation.

The descriptions of the models given in this manual are based on the technical specifications at the time of writing.

This manual covers all items of equipment (both standard and optional) available for these models, but whether or not these are fitted to the vehicle depends on the version, options selected and the country where the vehicle is sold.

This manual may also contain information about items of equipment to be introduced later in the model year.

The diagrams in the user manual are provided as examples.

Enjoy driving your new vehicle.

Translated from English. Copying or translation, in part or in full, is forbidden unless prior written permission has been obtained from the vehicle manufacturer.

CONTENTS

| | | | |
|--|-----------|--|------------|
| Welcome aboard your vehicle | 4 | Exterior lighting and signals | 69 |
| Exterior | 4 | Headlight beam adjustment | 70 |
| Passenger compartment | 6 | Audible and visual signals | 71 |
| Driver's position | 8 | Windscreen washing, wiping | 72 |
| Driving aids | 10 | Fuel tank | 74 |
| Safety on board | 12 | Driving | 76 |
| Identifying a vehicle - labels | 14 | Running in | 76 |
| The engine compartment (routine maintenance) | 16 | Starting, stopping the engine | 77 |
| Breakdown recovery | 18 | Gear lever, hand brake | 82 |
| Getting to know your vehicle | 20 | Special features of petrol versions | 83 |
| Keys, radio frequency remote control | 20 | Driver correction devices, aids | 84 |
| Radio frequency remote control | 22 | Take a break reminder | 87 |
| Card | 23 | Driving advice and ECO driving | 90 |
| "hands-free" card | 25 | Maintenance and antipollution advice | 94 |
| Locking and unlocking the doors | 29 | Environment | 95 |
| Opening and closing the doors | 32 | Tyre pressure monitoring system | 96 |
| Engine immobiliser | 34 | Automated manual transmission | 103 |
| Front seats | 35 | Parking distance control | 107 |
| Seat belts | 36 | Reversing camera | 109 |
| Methods of restraint in addition to the front seat belts | 41 | Your comfort | 111 |
| Side protection devices | 46 | Air vents, air outlets | 111 |
| Child safety | 47 | Heating, ventilation, air conditioning | 115 |
| Child seats | 50 | Windows | 117 |
| Driving position, right-hand drive | 53 | Interior lighting | 119 |
| Rear view mirrors | 55 | Sun visor/grab handle | 120 |
| Steering wheel, power-assisted steering | 56 | Passenger compartment storage | 121 |
| Warning lights | 57 | Accessories socket | 124 |
| Displays and indicators | 61 | Rear seats | 125 |
| Trip computer | 64 | Boot | 128 |
| Clock | 68 | Longitudinal roof bars | 129 |
| | | Multimedia equipment | 130 |

CONTENTS


| | | | |
|--|------------|--|------------|
| Maintenance | 132 | Anticorrosion check | 198 |
| Bonnet..... | 132 | Renault new vehicle warranty..... | 203 |
| Engine oil level..... | 134 | Renault new vehicle warranty..... | 203 |
| Levels, filters..... | 137 | Maintenance Appendix..... | 211 |
| Battery | 140 | Maintenance Appendix..... | 211 |
| Tyre pressure | 142 | Service and maintenance | 214 |
| Bodywork maintenance..... | 143 | Service and maintenance..... | 214 |
| Interior trim maintenance | 145 | Service checks | 216 |
| Practical advice | 147 | | |
| Puncture, emergency spare wheel..... | 147 | | |
| Wheel trim, tools..... | 149 | | |
| Changing a wheel | 151 | | |
| Tyres..... | 153 | | |
| Headlights, lights: changing bulbs | 159 | | |
| Fuses | 165 | | |
| Battery | 169 | | |
| Radio frequency remote control..... | 171 | | |
| Hands free card..... | 173 | | |
| Windscreen wiper - to lift/replace wiper blades..... | 175 | | |
| Towing..... | 177 | | |
| Installation and use of accessories | 179 | | |
| Operating faults..... | 181 | | |
| Technical specifications..... | 184 | | |
| Vehicle identification plates | 184 | | |
| Engine identification plates | 185 | | |
| Engine specifications | 186 | | |
| Dimensions (in metres) | 188 | | |
| Weights (in kg) | 190 | | |
| Replacement parts and repairs | 191 | | |
| Service sheets | 192 | | |



EXTERIOR

1

61821



4 - Welcome aboard your vehicle



EXTERIOR

1. Electric windows → 117

Windscreen wipers → 72

Demisting → 115

2. Rear view mirrors → 55

3. Card → 23

Locking/unlocking the doors → 29

4. Bodywork maintenance → 143


5. Tyres → 153

6. Lights: operation → 69

Lights: replacement → 159

PASSENGER COMPARTMENT

1



61822


PASSENGER COMPARTMENT

1. Adjusting your driving position → 36
2. Passenger compartment storage/
fittings → 121
3. Front seats → 35
4. Child safety → 32, → 47
5. Rear bench seat → 125

1

DRIVER'S POSITION

1



61823

8 - Welcome aboard your vehicle



DRIVER'S POSITION

1. Hand brake → 82
2. Gear lever → 82
3. Accessories socket → 124
4. Heating/Air conditioning system → 115
5. Multimedia screen → 130
6. Screen wash/wipe stalk → 72
7. Instrument panel → 57
8. Exterior lighting → 69
9. Key ignition switch → 77
10. Steering wheel adjustment → 56
11. Engine start/stop button → 77

DRIVING AIDS

1

53875



10 - Welcome aboard your vehicle



DRIVING AIDS

1. ABS (anti-lock braking system)
➔ **84**

ESC (electronic stability control) ➔
85

Braking assistance ➔ **84**

Hill start assistance ➔ **86**


2. Tyre pressure monitoring system
➔ **96**

3. Parking distance control ➔ **107**

4. Reversing camera ➔ **109**

SAFETY ON BOARD

1



61824


SAFETY ON BOARD

1. Front airbags → 41
2. Seat belts → 36
3. Side airbag → 46.

1

IDENTIFYING A VEHICLE - LABELS

1



61625


IDENTIFYING A VEHICLE - LABELS

1. Engine identification plate → 185
2. Tyre pressure labels → 142
3. Vehicle identification plates → 184

THE ENGINE COMPARTMENT (ROUTINE MAINTENANCE)

1

61925





THE ENGINE COMPARTMENT (ROUTINE MAINTENANCE)

1. Brake fluid → 137
2. Windscreen washer fluid → 137
3. Battery → 140
4. Opening the bonnet → 132
5. Engine oil → 134
6. Coolant → 137

1

BREAKDOWN RECOVERY

1



71509

BREAKDOWN RECOVERY

1. Replacing front windscreen wiper blade(s) → 175
 2. Replacing headlight bulbs → 159
 3. Front towing point → 177
 4. Replacing the rear screen wiper blade → 175
 5. Replacement of the rear lights → 160
 6. Fuses → 165
 7. Puncture → 147
- Tools → 149
- Emergency spare wheel → 147
- Changing a wheel → 151

KEYS, RADIO FREQUENCY REMOTE CONTROL

2

General information

Key A


44153



Depending on vehicle,
1. Coded key for ignition switch.

Radio frequency remote control key B

44154



Depending on vehicle,
2. Locks all the opening elements ;
3. Unlocks all opening elements ;
4. Driver's door and ignition/starter key.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

Radio frequency remote control operating range

This varies according to the surroundings : take care not to lock or unlock the doors by inadvertently pressing the buttons on the remote control.

Note : If a door or the luggage compartment lid is open or not closed

KEYS, RADIO FREQUENCY REMOTE CONTROL

properly, the doors and luggage compartment lid lock/unlock quickly.

Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the remote control) may affect the operation of the remote control.



Advice

Avoid leaving the remote control in hot, cold or humid areas.



Replacement and additional keys or remote controls.

You must only contact an approved dealer :

- If you need to replace a key it will be necessary to take the vehicle and all of its keys to an approved dealer in order to initialise the system.
- Depending on the vehicle, you have the option of using up to four remote controls.

Remote control unit failure

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. These batteries have a service life of approximately two years.

RADIO FREQUENCY REMOTE CONTROL

2

Use

Remote controls is used to lock or unlock the doors.

They are powered by a battery which can be replaced.

Locking the doors

Press locking button **1**.

Locking is confirmed by :

- the hazard warning lights and side indicator lights flashing **twice**.
- gradual dimming of the front daytime running lights.

If a door or the tailgate is open or not properly shut, the doors or tailgate lock then quickly unlock and the hazard warning lights and indicator lights do not flash.

Un locking the doors

44154



Pressing button 2 unlocks the opening elements.

Unlocking is confirmed by :

- the hazard warning lights and side indicator lights flashing **once**.
- the rear side lights flashing **twice** ;
- progressive lighting of the front daytime running lights



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

CARD

General information

43418



1. Unlocking the doors and tailgate.
2. Locking all doors and tailgate.
3. Unlocking/locking the tailgate.
4. Switching on the interior lighting remotely.

The card is used for :

- locking/unlocking the opening elements (doors, tailgate);
- switching on the vehicle interior lighting (refer to the following pages);
- starting the engine (refer to the information on "Starting the engine" in Section 2).

Battery life

Make sure that the correct battery type is being used, and that the battery is in good condition and inserted correctly. Its service life is approximately two years: replace it when the message "Keycard Battery Low" appears on the instrument panel (refer to section "Card : battery" in Section 5).

Card operating range

This varies according to the environment: take care not to accidentally lock or unlock the vehicle by inadvertently pressing the buttons on the card.

Note : if a door or the tailgate is open or not closed properly, the doors and tailgate lock then unlock quickly.

Interference

Interference by factors in the immediate vicinity (external installations or the use of equipment operating on the same frequency as the card) may disrupt its operation.



When the battery is flat, you can still lock/unlock and start your vehicle. Refer to the information on "Locking/unlocking the doors" in Section 1 and "Starting the engine" in Section 2.

2

Distance lighting function

43418



Pressing button 4 switches ON the interior lighting for approximately 20 seconds. This can be used, for example, to identify your vehicle from a distance when parked in a car park.

CARD

Note: Pressing button **4** again switches off the lighting.

2



Advice

Avoid leaving the card in hot, cold or humid areas.

Do not keep the card in a place where it could be bent or damaged accidentally, such as in a back pocket of a garment.



Replacement : need for an additional card

If you lose your card or require another, you can obtain one from an authorised dealer. If a card is replaced, it will be necessary to take the vehicle **and all its cards** to an approved Dealer to re-set the system. You may use up to four cards per vehicle.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

"HANDS-FREE" CARD

Use

There are two ways to unlock/lock the vehicle :

- the card in "hands-free" mode ;
- the card in remote control mode.



Do not store the card anywhere it may come into contact with other electronic equipment (computer, phone etc.) as this could hinder its operation.



Driver's responsibility when parking or stopping the vehicle


Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

Using the card in "hands-free" mode



44089

2

In "hands-free" mode, it is possible to lock/unlock the vehicle without using any of the card buttons, as long as the card is within the access zone 1.

Note : if the vehicle has not been used for more than 8 days, the hands-free system switches to standby. To reactivate it, press the unlocking button on the card.

"HANDS-FREE" CARD

2



44089

it lights up approximately for four seconds accompanied by a single beep sound.

Special features of the locking system

If a door is open or not properly closed, when you go away, the vehicle is not locked.

"Hands-free" unlocking/Approach unlock

Vehicle will get unlocked when the customer enters into the access zone **1** with the hands free card. Unlocking of the vehicle is indicated by one flash of the indicator lights and hazardous warning lights.

Remote "Hands-free" locking

With the card on you, and doors and tailgate closed, move away from the vehicle: it will lock automatically once you have left the access zone.

Note: The distance at which the vehicle locks depends on the surroundings.

Locking of the vehicle is indicated by one flash of the indicator lights and

26 - Getting to know your vehicle



44164

Particular features of the locking system (continued)

If the card has been within range for approximately 15 minutes, remote locking is disabled.

The vehicle will not lock if a card is in area **2**. If you unlock the vehicle by pressing the button on the card but do not open the doors or the boot,

"hands-free" remote locking is disabled.

Using the card as a remote control

43418



Unlocking with the card

Press button **3**.

Unlocking is indicated by **one flash** of the hazard warning lights and the indicator lights.

Locking using the card

With the doors and boot closed, press button **4**. The vehicle will lock. The hazard warning lights and rear indicator lights **flash twice** to indicate that the vehicle is locked.

"HANDS-FREE" CARD

Note: The maximum distance at which the vehicle locks depends on the surroundings.

Special features

If an opening element (a door or the luggage compartment) is open or not properly closed, the vehicle cannot be locked. The vehicle will lock/unlock in quick succession, but the hazard warning lights and the side indicator lights will not flash.

If you press button **4** for more than 5 seconds, "hands-free" mode is disabled until the next time you unlock the vehicle by pressing button **3**.

Activation or deactivation of "hands-free" mode is indicated by a beep.



The card buttons are deactivated when the engine is running.



43345

Locking/unlocking only the boot

43418



2

Press the button **5** to lock/unlock the boot only.

If, **while the engine is running**, a door is opened and closed, and the card is no longer in the zone **2**, the message "Keycard Not Detected" indicates that the card is not inside the vehicle. This will, for example, prevent you from driving away after dropping off a passenger who has kept the card on them.

The warning disappears when the card is detected again.

"HANDS-FREE" CARD

2



Driver's responsibility when parking or stop- ping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

**RISK OF DEATH OR SERIOUS IN-
JURY**

LOCKING AND UNLOCKING THE DOORS

If the remote control or, depending on the vehicle, the card does not work

In some cases, the radio frequency remote control or the card may not work:

- card/radio frequency remote control battery worn or run flat, vehicle battery flat etc.
- use of appliances operating on the same frequency as the card (mobile phone, etc.);
- vehicle located in a high electromagnetic radiation zone.

It is then possible:

- depending on the vehicle, use the radio frequency remote control or the emergency key integrated in the card to unlock the front right-hand door;
- to lock each of the doors manually;
- to use the interior door locking/unlocking control (refer to the following pages).

The card's built-in key



Slide the rear casing **1** downwards while pressing on zone **A**



Access with key **2**

The integrated **2** key is used to lock or unlock the front right-hand door if the card does not work.

2

Using the key integrated in the card



Insert the key **2** into the lock **3** and lock or unlock the front right-hand door.

Once you are inside the vehicle, put the key back in its casing in the card.

LOCKING AND UNLOCKING THE DOORS


Vehicles with key/remote control

2



From outside

Unlock the driver door using the key **4** into key barrel integrated in the front right-hand door handle.



From the inside

Push in button **5** to lock and lift button **5** to unlock. It is impossible to open the door if **5** is pushed in.



Never leave your vehicle with the key inside.

Interior locking/unlocking door control



If equipped, It simultaneously locks or unlocks all the doors and tail gate. Lock or unlock the doors by pressing switch **6**.

The front door mechanism cannot be locked if the door is open.

Locking the opening elements without the card or the radio frequency remote control key

For example, in the event of a discharged battery or the card or key temporarily not working etc.

LOCKING AND UNLOCKING THE DOORS

With the engine switched off and a door or tailgate open, press and hold the **6** switch for more than five seconds.

When the door is closed, all the doors and the tailgate will be locked.

Unlocking the vehicle from the outside is only possible with the card in the vehicle access zone or by using the key.



Driver's responsibility

If you decide to keep the doors locked when you are driving, remember that it may be more difficult for those assisting you to gain access to the passenger compartment in the event of an emergency.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

OPENING AND CLOSING THE DOORS

2

Opening the doors from the outside




With the doors unlocked → 29, place your hand on the handle **1** and pull towards you.

Special note

Depending on the vehicle, accessories (e.g. radio) stop working either when the engine is switched off or when the doors are locked.

Opening from the inside



Pull handle **2**.

Child safety



If equipped, this feature is to make it impossible for the rear doors to be opened from the inside, move lever **3** on each rear door and check from the inside that the doors are securely locked.

Lights-on reminder buzzer

If you have left the lights on after switching off the ignition, a warning buzzer will sound when a front door is opened (to prevent the battery from discharging, etc.).

Door/tailgate open buzzer


OPENING AND CLOSING THE DOORS

Depending on the vehicle, this alarm is fitted to the driver's side door or on all opening elements.

With the vehicle at a standstill, a

warning light  will come on if a door or the boot is open or not properly closed.

While driving, as soon as the vehicle reaches 20 km/h (12 mph), a warning

light  comes on with an audio beep.

Special note

Depending on the vehicle, accessories (e.g. radio) stop working either when the engine is switched off or when the driver's door is opened or when the doors are locked.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY



As a safety precaution, the doors should only be opened or closed when the vehicle is stationary.

ENGINE IMMOBILISER

(Depends on vehicle)

Engine Immobiliser prevents the vehicle from being driven by anyone not in possession of the vehicle's coded ignition key.

Operating principle

The vehicle is automatically protected a few seconds after the ignition is switched off.


If the vehicle does not recognise the coded ignition key or wrong key is used, the engine cannot be started.

System operation

When the ignition is switched on, the vehicle has recognised the code. You can then start the engine.

Vehicle protection

The vehicle will only be protected after the ignition has been switched off.



Operating faults

After the ignition has been switched on, if warning light 1 continues to flash or remains continuously lit, there is a system operating fault.

In all cases, it is essential to contact an approved dealer as they are qualified to repair the engine immobiliser.

If the coded ignition key is faulty, use the second key (supplied with the vehicle).



Any unauthorised work carried out on the engine immobiliser (computers, wiring, etc.) could be dangerous. Work must be carried out by qualified personnel.



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.


They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

FRONT SEATS

Move forward or backward




Hold the bar **1** at the centre and pull up the bar to move the seat forward or backward. Release the bar **1** in desired position of seat and ensure that the seat is fully locked into place.

To adjust the seat height

Lift the lever **2** upward/downwards to adjust the seat height and release the lever in the desired height. Ensure seat is locked properly after release.

To tilt the seatback



Lift the lever **3** upward to unlock recliner mechanism. Tilt the seat back to desired position and release the lever to lock the seatback in the desired position. Ensure seat back is locked properly by pushing/pulling the seatback.

To return the seatback to its original position, lift the lever **3** fully without applying any pressure to the seatback.

Ensure seat back is locked properly after pushing/pulling the seatback



For safety reasons, carry out any adjustments when the vehicle is not being driven.

Nothing should be placed on the floor (area in front of driver) as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.



We would advise you not to recline the seatbacks too far to ensure that the effectiveness of the seat belts is not reduced.

SEAT BELTS

Always wear your seat belt when travelling in your vehicle. You must also comply with the legislation of the particular country you are in.

Before starting, first adjust your driving position, then ask all occupants to adjust their seat belts to ensure optimum protection.

Adjusting your driving position

(depending on the vehicle)

- **Sit well back in your seat** (having removed your coat or jacket etc.). This is essential to ensure your back is positioned correctly.

- **adjust the distance between the seat and the pedals.** Your seat should be as far back as possible while still allowing you to depress the clutch pedal fully. The seatback should be adjusted so that your arms are slightly bent when you hold the steering wheel.



Make sure that the rear bench seat is locked in correct position so that the rear seat belts will operate efficiently.



Incorrectly adjusted or twisted seat belts may cause injuries in the event of an accident.

Use one seat belt per person, whether child or adult. Even pregnant women should wear a seat belt. In this case, ensure that the lap belt is not exerting too much pressure on the abdomen, but do not allow any slack.

Adjusting the seat belts



For correct adjustment and positioning of the seat belts at all seats:

- adjust the seats (seat position and seatback angle, if available);
- sit with your back firmly against the seatback;
- move the chest strap **1** as close as possible to the base of the neck without it actually resting against it (if necessary, adjust the height of the seat belt if available) and make sure that the chest strap **1** is in contact with the shoulder;
- position the lap belt **2** so that it lies flat on the thighs and against the pelvis.

The belt should be worn so that it is as close as possible to your body, i.e.: avoid wearing heavy clothing or keeping bulky objects under the belts, etc.

Locking

Unwind the belt **slowly and smoothly** and ensure that buckle **3** locks into latch **5** (check that it is locked by pulling on buckle **3**).

If the belt jams, allow it to return slightly before attempting to unwind it again.

If your seat belt is completely jammed, pull slowly, but firmly, so that just over 3 cm unwinds. Allow it

SEAT BELTS


to return slightly before attempting to unwind it again.


If there is still a problem, contact an approved dealer.

Unlocking

Press the button **4** on latch **5** and the seat belt will be rewound by the inertia reel. Hold by the buckle to make this easier.

Seat belt reminder light (Driver/Front Passenger seats)

 Depending on the vehicle, it comes on in the cluster when the ignition is ON and goes off after few seconds and if the driver's and/or passenger's seat belt is not fastened. When the vehicle is being driven, it comes on and a beep sounds for approximately 2 minutes until the driver's/passenger seat belt is fastened.

 an object placed on the passenger seat may activate the warning light in some cases, depending on the vehicle.

Rear seat belt reminder

(Depending on the Vehicle)

The **6** graphic is displayed on the instrument panel in below two states, This informs the driver fastening status of each of the rear seat belts every time:

- the ignition is switched on;
- Status of fastening or unfastening of a rear seat belt.



Understanding the graphic 6 :

- indicator filled: seatbelt fastened;
- indicator unfilled: seatbelt unfastened;

Depending on the vehicle, the **6** symbol appears when the ignition is switched ON, if a rear seat belt is

buckled state to unbuckled state or any state change. When the vehicle speed is less than approximately 12 mph (20 km/h), the **6** symbol appears for at least 65 seconds.

When the vehicle speed reaches or exceeds 12 mph (20 km/h), if one of the rear seat belts is or becomes unfastened during the journey:

- a beep is emitted for 35 seconds ; and
- the **6** symbol is displayed for at least 65 seconds and the symbol for the seat concerned changes to unfilled.

Always make sure that the rear passengers are properly fastened in and that the number of seat belts indicated corresponds to the number of rear seats occupied.

Rear seat belt reminder 7


(Depending on the Vehicle)

The **7** graphic is displayed on the instrument panel in below two states, This informs the driver fastening status of each of the rear seat belts every time:

- the ignition is switched on;
- Status of fastening or unfastening of a rear seat belt.

SEAT BELTS

2



Understanding the graphic 7:

- indicator green: seatbelt fastened;
- indicator red: seatbelt unfastened;

Depending on the vehicle, the **7** symbol appears when the ignition is switched ON, if a rear seat belt is buckled state to unbuckled state or any state change. When the vehicle speed is less than approximately 12 mph (20 km/h), the **7** symbol appears for at least 65 seconds.


When the vehicle speed reaches or exceeds 12 mph (20 km/h), if one of the rear seat belts is or becomes unfastened during the journey:

- a beep is emitted for 35 seconds ;
- and

- the **7** symbol is displayed for at least 65 seconds and the symbol for the seat concerned changes to red.

Always make sure that the rear passengers are properly fastened in and that the number of seat belts indicated corresponds to the number of rear seats occupied.

Seat with armrest(s)




Ensure that the seat belt is passed underneath the armrest **8** , check that the buckle **11** is fastened in the latch **10**.

Lower the armrest **8** (movement **A**).

Unwind the belt **slowly** and **smoothly**.

Pass the shoulder strap under the armrest **8**. Make sure the buckle locks into the latch (check that it is locked by pulling on the buckle).

Adjusting the rear seat belts




Adjusting the second row side seat belts

Slowly unwind belt **9** and click latch **10** into red buckle **11**. Before folding down a rear side seat, buckle the seat belt concerned in its corresponding catch.

This will prevent the seat belt becoming trapped when the seat is returned to its position for use.

In all cases, check that the seat belts are operating correctly.

SEAT BELTS



Adjusting the second row centre seat belts (depending on vehicle)

Fasten sliding latch **12** into the red buckle **13**.



Adjusting the third row side seat belts

Fasten latch **14** into the red buckle **15**.

Adjust the seat belt strap as indicated in the image for height adjustment.



Check that the rear seat belts are positioned and operating correctly each time the rear bench seat is moved.



- No modification may be made to the component parts of the originally fitted restraint system: seat belts, seats and their mountings. For special operations (e.g. fitting child seats), contact an authorised dealer.
- Do not use devices which allow any slack in the belts (e.g. clothes pegs, clips, etc.): a seat belt which is worn too loosely may cause injury in the event of an accident.
- Never wear the shoulder strap under your arm or behind your back.
- Never use the same belt for more than one person and never hold a baby or child on your lap with your seat belt around them.
- The belt should never be twisted.
- Following an accident, have the seat belts checked and replaced if necessary. Always replace your seat belts as soon as they show any signs of wear.

SEAT BELTS

2

- When the rear bench seat is being put back, make sure that the seat belts and buckles are correctly positioned so that they can be used properly.
- Make sure that the buckle is inserted into the appropriate catch.
- Ensure that no objects are placed in the area around the seat belt catch as they could prevent it from being properly secured.
- Make sure the seat belt catch is properly positioned (it should not be hidden away, crushed or flattened by people or objects).

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS

Depending on the vehicle, they will consist of :


- **seat belt inertia reel pretensioners ;**
- **chest-level load limiters ;**
- **air bags for driver and front passenger.**

These systems are designed to act independently or together when the vehicle is subjected to a frontal impact.

Depending on the severity of the impact, the system can trigger :

- seat belt locking ;
- the seat belt inertia reel pretensioner (which engages to correct seat belt slack) ;
- airbags.

Pretensioners



The pretensioners (in driver side) hold the seat belt against the body, holding the occupant more securely against the seat, thus increasing the seat belt's efficiency.

With the ignition on, following a significant frontal impact and depending on the severity of the impact, the system may trigger the seat belt inertia reel pretensioner **1**, which instantly retracts the seat belt.



- Have the entire restraint system checked following an accident.
- No operation whatsoever is permitted on any part of the system (pretensioners, air bags, computers, wiring) and the system components must not be reused on any other vehicle, even if identical.
- To avoid incorrect triggering of the system which may cause injury, only qualified personnel from an approved Dealer may work on the pretensioner and air bag system.
- The electric trigger system may only be tested by a specially trained technician using special equipment.
- When the vehicle is scrapped, contact an approved Dealer for disposal of the pretensioner and air bag gas generators.

Load limiter

Above a certain severity of impact, this mechanism is used to limit the

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS


force of the belt against the body so that it is at an acceptable level.

2 Airbags for driver and front passenger

Fitted to the driver and passenger side.

The presence of this equipment is indicated by the word "Air bag" on the steering wheel and dashboard (air bag zone **A**) and, depending on the vehicle, a symbol on the lower section of the windscreen.

Each air bag system consists of :

- an air bag and gas generator fitted on the steering wheel for the driver and in the dashboard for the front passenger ;
- an electronic unit for system monitoring which controls the gas generator electrical trigger system ;
- a single  warning light on the instrument panel.



The air bag system uses pyrotechnic principles. This explains why, when the air bag inflates, it will generate heat, produce smoke (this does not mean that a fire is about to start) and make a noise upon detonation. In a situation where an air bag is required, it will inflate immediately and this may cause some minor, superficial grazing to the skin or other problems.




Operation

This system is only operational when the ignition is switched on.

In a severe **frontal** impact, the air bags inflate rapidly, cushioning the impact of the driver's head and chest against the steering wheel and of the front passenger against the dashboard. The air bags then deflate immediately so that the passengers are not in any way hindered from leaving the vehicle.

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS

Operating faults




46017

This warning light **2**  will light up on the instrument panel when the ignition is switched on and then go out after a few seconds.


If it does not light up when the ignition is switched on, or comes on when the engine is running, there is a fault in the system.

Contact your approved Dealer as soon as possible. Your protection will be reduced until this fault is rectified.



44446

The following cases cause the pretensioners or airbags to operate.
In a frontal impact against a rigid (non-deformable) surface at an impact speed equal or greater than 25 km/h (16 mph)




44448

In a frontal impact with another vehicle of an equivalent or higher category, with an impact area equal to or greater than 40 %, where the speed of both vehicles is equal or greater than 40 km/h (25 mph).

2

METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS





44452



44450




44449



44451

In the following examples, the pretensioners and airbags might not operate :

- in the event of a rear impact, however severe ;
- if the vehicle overturns.



- in the event of a side impact, affecting the front of the vehicle ;
- in the event of a frontal impact, under the tail of a lorry
- in the event of a frontal impact against an obstacle with a sharp angle ;

In the following examples, the pretensioners and airbags could operate :



METHODS OF RESTRAINT IN ADDITION TO THE FRONT SEAT BELTS

All of the warnings below are given so that the air bag is not obstructed in any way when it is inflated and also to prevent the risk of serious injuries caused by items which may be dislodged when the air bag inflates.

2



Warnings concerning the driver's air bag

- Do not modify the steering wheel or the steering wheel boss.
- Do not cover the steering wheel boss under any circumstances.
- Do not attach any objects (badge, logo, clock, telephone holder, etc.) to the steering wheel boss.
- The steering wheel must not be removed (except by qualified personnel from our Network).
- When driving, do not sit too close to the steering wheel. Sit with your arms slightly bent (see the information on "Adjusting your driving position" in Section 1). This will allow sufficient space for the air bag to deploy correctly and be fully effective.

Warnings concerning the passenger air bag

- Do not attach or glue any objects (badge, logo, clock, telephone holder, etc.) to the dashboard on or near the air bag.
- Do not place anything between the dashboard and the passenger (pet, umbrella, walking stick, parcels, etc.).
- The passenger must not put his or her feet on the dashboard or seat as there is a risk that serious injuries may occur. In general, parts of the body should be kept away from the dashboard (knees, hands, head, etc.).
- The devices in addition to the front passenger seat belt should be reactivated as soon as a child seat is removed, to ensure the protection of the passenger in the event of an impact.

A REAR-FACING CHILD SEAT MUST NOT BE FITTED TO THE FRONT PASSENGER SEAT

SIDE PROTECTION DEVICES

2

Side Airbags

Depending on vehicle, these airbags may be fitted at the sides of the front seats and are deployed at the sides of the seats (door side) to protect the occupants in the event of a severe side impact.



Depending on the vehicle, a marking on the windscreen informs you of the presence of additional means of restraint (air bags, pretensioners, etc.) in the passenger compartment.



Warnings concerning the side air bag

– **Fitting seat covers :** seats equipped with an airbag require covers specifically designed for your vehicle. Contact an authorised dealer to find out if these covers are available.

The use of any covers other than those designed for your vehicle (including those designed for another vehicle) may affect the operation of the airbags and reduce your protection.

– In the front, do not place any accessories, objects or even pets between the seatback, the door and the internal fittings. Do not cover the seatback with objects such as clothes or accessories. This may prevent the airbag from operating correctly or cause injury when the airbag is deployed.

– No work or modification whatsoever may be carried out on the seat or internal fittings, except by qualified personnel from an approved dealer.

CHILD SAFETY

General information

Carrying children

Children, and adults, must be correctly seated and strapped in for all journeys. The children being carried in your vehicle are your responsibility.

A child is not a miniature adult. Children are at risk of specific injuries as their muscles and bones have not yet finished growing. The seat belt alone would not provide suitable protection. Use an approved child seat and ensure you use it correctly.

CHILD RESTRAINT SEAT provision is given in Rear Left seat belt.



To prevent the doors being opened, use the childproof locks → 32.



It is recommended that children and infants are seated in child restraint.

You choose a child restraint that fits your vehicle. Always follow the manufacturer's instruction for installation and use. In addition there are many types of child restraint available for larger children that should be used for maximum protection.



A collision at 50 km/h is the same as falling a distance of 10 metres.

Transporting a child without a restraint is the equivalent of allowing him or her to play on a fourth-floor balcony without railings. Never travel with a child held in your arms. In the event of an accident, you will not be able to keep hold of the child, even if you yourself are wearing a seat belt. If your vehicle has been involved in a road accident, replace the child seat and have the seat belts and fittings checked.

CHILD SAFETY



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone on your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or by locking the doors. Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY.

Using a child seat

The level of protection offered by the child seat depends on ability to restrain child and on its installation. Incorrect installation risks the protection of the child in the event of harsh braking or an impact.

Before purchasing a child seat, check that it complies with the regulations and that it can be fitted in

your vehicle. Consult an approved dealer to find out which seats are recommended for your vehicle. Before fitting a child seat, read the manual and respect its instructions. If you experience any difficulties during installation, contact the manufacturer of the equipment. Keep the instructions with the seat.



Set a good example by always fastening your seat belt and teaching your

child :

- to strap themselves in correctly.
- to always get in and out of the car at the kerb, away from busy traffic.

Do not use a second-hand child seat or one without an instruction manual.

Check that there are no objects in the vicinity of the child seat which could impede its operation.



Never leave a child unattended in the vehicle. Check that your child is always strapped in and

that the belt or safety harness used is correctly set and adjusted. Avoid wearing bulky clothing which could cause the belts to slacken → 36.

Never let your child put their head or arms out of the window. Check that the child is in the correct position for the entire journey, especially if asleep.

CHOOSING A CHILD SEAT MOUNTING

Attachment via the seat belt

The seat belt must be adjusted in order to ensure it works in the event of sudden braking or impact

Ensure that the strap paths indicated by the child seat manufacturer are respected

Always check that the seat belt is correctly fastened by pulling it up, then pulling it out fully whilst pressing on the child seat.

CHILD SAFETY


Check that the seat is correctly held by moving it from side to side and back to front : the seat should remain firmly fixed.

Check that the child seat has not been installed at an angle and that it is not resting against a window.

Fitting a child, general information

Some seats are not suitable for fitting child seats. The diagram on the following page shows you how to attach a child seat.


The types of child seats indicated may not be available. Before using a different child seat, check with the manufacturer that it can be fitted.



Fit the child seat in rear seat.
Check that when installing the child seat in the vehicle it is not at risk of coming loose from its base. If you have to remove the headrest, check that it is correctly stored so that it does not come loose under harsh braking or impact. Always attach the child seat to the vehicle even if it is not in use so that it does not come loose under harsh braking or impact.


- move the seat in front of the child forwards, and set the position of the seatback to avoid contact between the seat and the child's legs.

Check that the child seat is resting against the back of the rear seat.



Ensure that the child seat or the child's feet do not prevent the front seat from locking correctly → 35.

47205



Since front passenger airbag triggering and the position of a rear-facing child seat are incompatible, NEVER use a rear-facing child restraint on a seat with an airbag.
The airbag could cause SERIOUS OR FATAL INJURY if inflated.

In the rear side seat

A carrycot can be installed across the vehicle and will take up at least two seats. Position the child with his or her feet nearest the door. Move the front seat as far forward as possible to install a rear-facing child seat, then move back the seat in front as far as it will go, although without allowing it to come into contact with the child seat.


For the safety of the child in the forward-facing seat,



CHILD SEATS

Attachment by seat belt

2



56958

CHILD SEATS



RISK OF DEATH OR SERIOUS INJURY : never fit a child seat on the front seat if the vehicle has a passenger airbag which cannot be deactivated.

2



Using a child safety system which is not approved for this vehicle will not correctly protect the baby or child. They risk serious or even fatal injury.



Check that your child is always strapped in and that the belt or safety harness used is correctly set and adjusted → 36. If necessary, adjust the seat position accordingly.

Child seat attached using the belt



Seat which allows a child seat with "Universal" approval to be attached by a seat belt.



Seat not suitable for fitting child seats.

CHILD SEATS

Installation table

2

The table below summarises the information already shown in the diagram on the following pages, to ensure the applicable regulations are respected.


| Seating Position | | | | | | | |
|------------------|---------------------|----------------------|------------------|-------|--------|-----------------|-------|
| Mass Group | Weight of the child | Front passenger seat | Second row seats | | | Third row seats | |
| | | | LEFT | RIGHT | CENTRE | LEFT | RIGHT |
| Group 0 | Upto 10 kg | X | U | U | X | X | X |
| Group 0+ | Upto 13 kg | X | U | U | X | X | X |
| Group I | 9 to 18 kg | X | U | U | X | X | X |
| Group II | 15 kg to 25 kg | X | U | U | X | X | X |
| Group III | 22 kg to 36 kg | X | U | U | X | X | X |

X= Seat not suitable for fitting child seats.

U= Seat which allows a child seat with "Universal" approval to be installed using a seat belt ; check that it can be fitted.

DRIVING POSITION, RIGHT-HAND DRIVE

Driving position, right-hand drive



44203

2


DRIVING POSITION, RIGHT-HAND DRIVE

The presence of the equipment DEPENDS ON THE VEHICLE VERSION AND COUNTRY.

1. Left side air vent
2. Location for left tweeter
3. Upper Glove Box
4. Centre air vents
5. Steering column stalk for wind-screen wash / wiper
6. Instrument panel
7. Location for driver's airbag
8. Trip switch
9. Location for right tweeter
10. Right side air vent
11. Steering column stalk for direction indicator lights / exterior lights,
12. Head light beam height adjustment control
13. Horn
14. Steering wheel height adjustment
15. Electronic stability control switch
16. Heating and ventilation controls
17. Start/Stop switch
18. Handbrake
19. 12V Accessories socket
20. Rear AC switch
21. Rear console cooled box
22. Gear lever
23. Location for cup holder
24. USB/AUX port (for changing + media connect)
25. Hazard warning lights switch
26. Location for radio/Navigation System
27. Lower Glove Box

REAR VIEW MIRRORS

Exterior rear view mirror



(depending on the version)

Electric adjustment

With ignition ON, turn rotary knob **1** to position :

- position **A** to adjust the right-hand door mirror;
- position **C** to adjust the left-hand door mirror;
- **B** is the inactive position.

Folding door mirrors


(depending on vehicle)

Turn knob **1** to position **D** to fold the door mirrors **2**. To reset them for driving, return to position **B**. If the door mirrors are folded manually, turn the

knob **1** to position **D** and then to position **B** to reset.



For safety reasons, carry out any adjustments when the vehicle is not being driven.



Manual Adjustment

Adjust the door mirror according to rear vision by adjusting the knob **3**.

Foldable door mirrors


The door mirrors can be folded : simply fold them manually against the door window.



Objects observed in the door mirror glass are actually closer than they appear. For your safety, take this into account in order to correctly assess the distance before any manoeuvre.

2

Interior rear view mirror




The interior rear-view mirror **4** is manually adjustable. When driving at night, tilt the mirror by lever **5** or by hand to avoid being dazzled by the headlights of the vehicle behind.

STEERING WHEEL, POWER-ASSISTED STEERING

2

Steering wheel height adjustment



Raise the lever **1** and place the steering wheel in the required position ; lower the

lever to lock the steering wheel.

Make sure that the steering wheel is correctly locked.

Power Assisted Steering

Never drive with an inadequately charged 12V battery.

Variable power assisted steering

The variable power-assisted steering system is equipped with an electronic control system which alters

the level of assistance to suit the vehicle speed.

Steering is made easier during parking manoeuvres (for added comfort) while the force needed to steer increases progressively as the speed rises (for enhanced safety at high speeds).



Never leave the steering wheel on full lock when the vehicle is stationary.



With the engine switched off, or if there is a system fault, it is still possible to turn the steering wheel. The force required will be greater.



For safety reasons, only adjust the steering wheel when the vehicle is stationary.



Never switch off the ignition when travelling downhill, and avoid doing so in normal driving (power steering and brake servo will not function).

WARNING LIGHTS


The presence and operation of the warning lights **DEPEND ON THE EQUIPMENT AND COUNTRY.**



Instrument Panel A



If no lights or sounds are apparent, this indicates a fault in the instrument panel. This indicates that it is essential to stop immediately (as soon as traffic conditions allow). Ensure that the vehicle is correctly immobilised and contact an approved Dealer.



Instrument Panel B



Orange warning light



comes on while you are driving, **drive carefully** to an authorised dealer as soon as possible. Failure to follow this recommendation risks damaging your vehicle.



Main beam headlight tell-tale light.



Dipped beam headlight tell-tale.



Left-hand direction indicator tell-tale.



Right-hand direction indicator tell-tale.



Gear change indicator

This lights up to advise you to change to a higher gear (up arrow) or lower gear (down arrow).



The red warning light



requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an Authorised Dealer.

Over Speed Warning beep

Primary Warning

When vehicle speed exceeds around 80 km/h (50 MPH), a beep sounds for every 2 minutes until the driver re-

WARNING LIGHTS

duces the speed less than 80 km/h (50 MPH)

2

Secondary Warning

When vehicle speed exceeds around 120 km/h (75 MPH), a beep sounds for every 2 seconds until the driver reduces the speed less than 120 km/h (75 MPH), after which it will switch to the primary warning.

Handbrake "on" warning light and brake circuit incident warning light

This comes on when the ignition is switched on and goes out when parking brake is dis-engaged. If it comes on during braking and is accompanied by a beep, it indicates that fluid level in circuit is low. It may be dangerous to continue driving. Contact approved dealer.

Variable power-assisted steering warning light

Warning light (orange)

When engine gets off suddenly (e.g., in traffic conditions), it lits up till the engine gets started. There is no functional effect and is the normal functioning of the car.

Warning light (red)

It lights up when the ignition is switched on and goes off after a few seconds. If it lits while driving, it indicates that there is a fault in the system.

At this time, greater efforts are required to operate the steering wheel. Contact your approved Dealer as soon as possible.

Variable power-assisted steering warning light

When engine gets off suddenly (e.g., in traffic conditions), it lits up till the engine gets started. There is no functional effect and is the normal functioning of the car.

Warning light (red)

It lights up when the ignition is switched on and goes off after a few seconds. If it lits while driving, it indicates that there is a fault in the system.

At this time, greater efforts are required to operate the steering wheel. Contact your approved Dealer as soon as possible.

Anti-lock braking warning light

This lights up when the ignition is switched on and goes out after a few seconds.

If it does not goes out after the ignition is switched on, or lights up when driving, there is a fault with the ABS. Braking will then be as normal, without the ABS system.

Contact an approved Dealer as soon as possible.

Battery charge warning light

If it comes on when you are driving, it indicates that the circuit has discharged. Consult an approved Dealer as soon as possible.

Air bag warning light

This comes on when the ignition is switched on and goes out after a few seconds.

If it does not goes out when the ignition is switched on, or comes on when the engine is running, there is a fault in the system.

Contact your approved Dealer as soon as possible.

WARNING LIGHTS



Warning light



means you should drive very carefully to an approved dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.



Door(s) open warning light

Refer to "Opening/closing the doors" in → 32

Depending on the variants, if any of the door is opened, warning light will come ON indicating the exact door location in open condition accompanied by a warning message, "DOOR OPEN" in the instrument panel.



Warning light malfunction (red or orange)

Warning light (orange)

This lights up when the ignition is switched on and goes out after 3 seconds. It may come on in conjunction with other warning lights on the instrument panel. It means you should **drive very carefully** to an authorised dealer as soon as possible.

If you fail to follow this recommendation, you risk damaging your vehicle.

Urgent stop warning light (red)

This lights up when the ignition is switched on and goes out as soon as the engine is started and is accompanied by a beep. It requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it. Contact an approved Dealer.

STOP Stop light

This lights up when the ignition or engine is switched on and goes out as soon as the engine is running. It comes on with other warning lights and/or messages on the instrument panel.

It requires you to stop immediately, for your own safety, as soon as traffic conditions allow. Switch off the engine and do not restart it.

Contact an approved Dealer.



Warning light

This lights up when the ignition or engine is switched on and goes out as soon as the engine is running. It can light up in conjunction with oth-

er warning lights and/or messages on the instrument panel.

It means you should **drive very carefully** to an approved dealer as soon as possible. If you fail to follow this recommendation, you risk damaging your vehicle.



Oil pressure warning light

This comes when ignition is ON and goes out after few seconds. If it comes on when you are driving accompanied and a beep, it is essential to stop and switch off the ignition. Contact an approved Dealer.



Warning light for monitoring exhaust gas

It comes on when the ignition is switched on and then goes out.

- If it lights up continuously, consult an approved dealer as soon as possible.
- If it flashes, reduce the engine speed until the light stops flashing. Contact your approved Dealer as soon as possible.

Refer to the information on "Advice: antipollution, fuel economy, driving" in Section 2.

WARNING LIGHTS

2



Warning light for the electronic stability program (ESC) and traction control system

There are several reasons for the warning light to come on: see "Electronic Stability Program ESC with understeer control and traction control" in → 84



Indicator light ESC

Refer to the information on "Driving correction devices and aids" in → 85



Low fuel level warning light

This warning light gets ON when ignition is ON and remains lit permanently (or) depending on the variant, the warning light goes off after few seconds

Depending on the variants, if it blinks (or) gets ON when driving and accompanied by a beep, it indicates the fuel level is getting low. Fill up with fuel as soon as possible

Depending on the variants, if the fuel last bar starts blinking, fill up with fuel as soon as possible.

Before starting the vehicle, always check the fuel level indicator in the instrument panel



Coolant temperature warning display

This bar display comes ON when ignition is ON and remains lit permanently (or) depending on the variant, the warning light goes off after few seconds

Depending on the variants, if it blinks (or) gets ON when driving, this means the engine is overheating. Stop and allow the engine to run at idle speed for a minute or two. The temperature should drop. If not, stop the engine. Let it cool down. Contact an authorised dealer if necessary.



Oil pressure warning light

This comes when ignition is ON and goes out after few seconds. If it comes on when you are driving accompanied and a beep, it is essential to stop and switch off the ignition. Contact an approved Dealer



Tyre under-inflation warning light

It lights up when the ignition or the engine is switched on and goes off after a few seconds. → 96

DISPLAYS AND INDICATORS


Instrument panel A




This is applicable depending on the variant.

It lights up when the ignition is switched on. In some cases, the appearance of a warning light is accompanied by a message.

Rev counter 1 (rpm X1000)



Trip Computer 2



Coolant temperature warning display 3 → 57

Fuel level warning display 4 → 57

Instrument panel B




This is applicable depending on the variant.

It lights up when the ignition is switched on. In some cases, the appearance of a warning light is accompanied by a message.

DISPLAYS AND INDICATORS

2



65862

Instantaneous/Average fuel consumption **5**

Rev counter (rpm X1000) **6**

Trip distance recorder **7**

Estimated range with remaining fuel **8**

Total distance recorder **9**


Gear mode display **10**

Gear shift display **11**



65863

Service due reminder display **12**



65865

Instantaneous fuel economy **13**

Average fuel economy **14**




65864

Display to change the settings **15**

This display will allow you to customise the **brightness** of the display in both day and night mode.

DISPLAYS AND INDICATORS



Fuel economy history display 16
Warning lights indicator 17, 18


When driving, if multiple tell-tale lights triggered, the lights **17, 18** will rotate for every 4 seconds.

TRIP COMPUTER

General information

2

Trip computer A




The display depends on the vehicle and the country.

Scroll through the following information by pressing the button **1**.

Trip computer B

The display depends on the vehicle and the country.

Press the **2** switch to browse between menus and select functions by repeatedly pressing the **3** or **4** switch, then if necessary use the **5** switch to confirm "OK".



- a) Total distance recorder.
- b) Trip distance recorder.
- c) Fuel used in litre (from last reset).
- d) Average fuel consumption (from last reset).
- e) Current fuel consumption.
- f) Estimated fuel range (DTE - distance to empty).
- g) Distance travelled from last reset.
- h) Average speed from the last Reset.
- i) Display settings
- j) Service reminder

Resetting the trip mileage

To reset the trip mileage recorder, the display must show the Trip meter function.

Press and hold button **1**.

Interpreting some of the values displayed after resetting

The values showing average fuel consumption, range and average speed will become more stable and reliable the further you travel after pressing the reset button.

For the first few kilometres after pressing the reset key you will notice that the range increase/decrease as you travel. This range takes into account the average fuel consumption since the last time the reset button was pressed.

Refer to the table on the following pages showing display examples.

The current fuel consumption may increase when,

- the vehicle stops accelerating.
- the engine reaches its operating temperature (if the engine was cold when the reset key was pressed).
- when driving from an urban area onto the open road.

TRIP COMPUTER

Resetting is automatic when the maximum capacity of any of the memories is exceeded.

TRIP COMPUTER

Journey parameters

2

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

| DISPLAY | Interpreting the display selected |
|---------|---|
| | Total distance recorder |
| | Trip distance recorder |
| | Fuel used (since the last time the reset button was pressed) |
| | Average fuel consumption (since the last time the reset button was pressed) This value is displayed after driving 400 metres. This takes into account the distance travelled and the fuel used since the last time the reset button was pressed. |





The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

| DISPLAY | Interpreting the display selected |
|---------|--|
| | Current fuel consumption |
| | Estimated range with remaining fuel |
| | Distance travelled (since the last time the reset button was pressed for TRIP B) |
| | Average speed (since the last time the reset button was pressed) |
| 16:30 | Time taken to travel the distance |

The display of information shown below **DEPENDS ON THE VEHICLE EQUIPMENT AND COUNTRY.**

| DISPLAY | Interpreting the display selected |
|---------|-----------------------------------|
|---------|-----------------------------------|


TRIP COMPUTER

| | | | |
|---|---|------------------------|--|
| SERVICE INTERVALS |  | Service 1000KM/12month | <p>Mileage before service</p> <p>With the ignition switched on, the engine not running and the display set to "SERVICE INTERVALS", press the button 1 or 2 for approximately 10 seconds to display the mileage before service (distance or time to the next service). When the distance value approaches its limit, there are several possible scenarios :</p> <ul style="list-style-type: none"> - distance/time remaining is less than 1500 km or one month : the message "Service" is displayed accompanied by the nearest term (distance or time) ; - distance equals 0 km or date of service reached : the message "Service required" is displayed and depending on the variants accompanied by warning light  . <p>The vehicle requires a service as soon as possible.</p> |
| |  | Service 100KM/20days | |
| |  | Service required | |
| <p>Resetting : to reset the distance before service, press and hold button 1 for approximately 10 seconds until the display shows the service mileage without flashing.</p> <p>NB : if a service is performed without changing the engine oil, only the mileage before the next service should be reset. In the event of an oil change, both the distance before the next service and the next oil change should be reset.</p> | | | |

CLOCK

Display A

2



To access the display **2** for setting the time, press button **1** and Wait a few seconds ; the hours and minutes will begin to flash. You are now in setting mode, press and hold button **1**.

Wait a few seconds, the minutes will flash : repeatedly press or press and hold button **1** to set the time. When setting is complete, the hours and minutes remain displayed continuously for 2 seconds : your setting is registered.

You may change the display.


2




If the power supply is cut (battery disconnected, supply wire cut, etc.), the clock must be reset. We recommend that you do not adjust these settings while driving.

EXTERIOR LIGHTING AND SIGNALS


44033




Side lights

 Turn the end of stalk **2** until the symbol is opposite mark **1**.

Dipped beam headlight


 Depending on the vehicle, turn the end of stalk **2** down until the symbol is opposite mark **1**.

Main beam headlights

 With the dipped beam headlights lit, push down stalk **3**. The indicator on instrument panel comes

on. To return to dipped headlight, pull the stalk **3** upward.

Switching off the lights

 Turn the end of stalk **3** until the symbol is opposite mark **2**.

Headlight flasher : Pull stalk **3** towards you to flash the headlights.


Daytime running lights function (front lights only)

If fitted on the vehicle, the daytime running lights come on automatically with no action on stalk, when the engine is started and they go off once the engine is switched off. When the position function is ON, the daytime running lights are switched off.

2

HEADLIGHT BEAM ADJUSTMENT

2



Knob **A** is used to adjust height of the headlight beam according to load. Turn knob **A** anticlockwise to lower the beams and clockwise to raise them.

| | |
|--|----|
| these seats occupied | |
| Driver + Luggage in boot | o |
| Passenger in all seats | oo |
| Passenger in all seats + Luggage in boot | oo |

| | Examples of positions for adjusting the knob A according to the load |
|--|---|
| Only Driver | Zero |
| Driver + front passenger | Zero |
| Driver + Passenger in front seat + Rear Far- | o |


AUDIBLE AND VISUAL SIGNALS


Horn



Press on the centre or sides of the highlighted (horn pad) **1** to use the horn.

Hazard warning lights




 Press switch **2**.

This switch activates all four direction indicators and the side indicator lights simultaneously.

It must only be used in an emergency to warn drivers of other vehicles that you have had to stop in an area where stopping is prohibited or unexpected, or that you are obliged to drive under special conditions.

Direction indicators



Move stalk **3** parallel to the steering wheel and in the direction you are going to turn it.


When driving on motorway, the steering is not usually turned sufficiently to enable the stalk to return automatically to home position. There is intermediate position where the stalk will not be held for lane change indication and there will be 3 blinks of indicator lights in dedicated direction.

If it does not return back automatically, release the stalk manually and it will return to its home position.


2

WINDSCREEN WASHING, WIPING

2



Windscreen wiper

 With the ignition on, move the stalk **1** around the steering wheel (depending on the version):

- A.** One time Mist removal function.
- B.** Park ;
- C.** Intermittent wiping (depends on vehicle version) - The wiper will pause for several seconds between sweeps.
- D.** Normal wiping speed.
- E.** Fast wiping speed.

Windscreen washer

 With the ignition on, pull stalk **1** towards you.

A brief pull will trigger a single sweep of the wipers, in addition to the windscreen washer.

A longer pull will trigger three sweeps of the wipers, in addition to the windscreen washer.



When working in the engine compartment, ensure that the windscreen wiper stalk **1** is in the **B** position (park). **Risk of injury.**



Before any action on the windscreen (washing the vehicle, de-icing, cleaning the windscreen, etc.), return stalk **1** to position **B** (park). **Risk of injury and/or damage.**



Efficiency of a wiper blade

Check the condition of the wiper blades. How long they last depends on you:

- it must remain clean : clean the blade and the screen regularly with soapy water;
- do not use it when the screen is dry;
- free it from the screen when it has not been used for a long time.

In all cases, replace it as soon as it begins to lose efficiency : approximately once a year.

Precaution for using the wipers

- In freezing or snowy weather conditions, clear the screen before starting the wipers (risk of wiper motor overheating);
- ensure that no objects are obstructing the travel of the blade.

WINDSCREEN WASHING, WIPING

Rear screen wiper

44078



Do not use the wiper arm to open or close the tail-gate.

Heated rear screen



44167



With the ignition on, turn the end of stalk **1** to align the symbol with mark **2**.

Rear screen washer/wiper



With the ignition on, turn the end of stalk **1** to align the symbol with mark **2**.

When the stalk is released, it returns to the rear wipe position.



Depending on the variants, with the engine running, press button **3** (the indicator light on the instrument panel lights up).

This function de-ices/demists the rear screen.


The function is stopped :

- automatically after a period of time set by the system (warning light goes out);
- by pressing button **3** again (the warning light goes out).

2

FUEL TANK

2




Opening the Fuel Flap

- Stop the Engine.
- Pull up the fuel filler flap release lever **1** located on the floor, right front side of driver's seat which unlocks the fuel filler flap **A**.
- Turn the fuel filler cap **2** counter-clockwise slowly and completely unscrew the cap.
- Remove the cap.



Do not wash the filler area with a high-pressure washer.



- After refuelling, replace cap. Turn it clockwise and screw completely.
- Push the fuel filler flap **A** closed until it latches.

For details on filling the tank, refer to the information on "Filling with fuel".

NOTE: In cold weather, if the fuel flap does not open, tap the door lightly. Then try to open it again.



Fuel filler cap: this is a specific type. If you

have to replace it, make sure the new cap

is of the same type as the original. Contact an approved Dealer. Never place the cap near a source of heat or flame.

Do not add any additives to the fuel, you risk damaging the engine.

Do not wash the filler area with a high-pressure washer.

Fuel grade

Use a high-grade fuel that complies with the legislation in force in each country and which must comply with the specifications given on the label on fuel flap **A** → 186.

Petrol version

It is essential to use unleaded petrol. The octane rating (RON) must comply with the information provided under → 186.

FUEL TANK



Fuels that comply with the Indian standards with which vehicle engines marketed in India are compatible → 186.



To fill up with fuel, the engine must be stopped (and not only in standby for the vehicle fitted with the Stop and Start function): you must switch off the ignition → 77.
Fire hazard.



Do not use ethanol-based fuel if your vehicle is not compatible with this fuel.
Do **not** add reagent to the fuel otherwise you risk damaging the engine. If you wish to add an additive to the fuel, use a product approved by our Technical Department.
Consult an approved Dealer.



No modifications whatsoever are permitted on any part of the fuel supply system (electronic unit, wiring, fuel circuit, injector, protective covers, etc.) as this may be dangerous (unless undertaken by qualified Network personnel).

Filling up with fuel

With the ignition off, insert the nozzle **fully** before turning it on to fill the fuel tank (risk of splashing).

Keep the nozzle in this position throughout the entire filling operation. When the pump cuts out automatically at the end of the filling procedure, a maximum of two further filling attempts may be made, as there must be sufficient space in the fuel tank to allow for expansion.

Make sure that no water enters the fuel tank during filling.

After filling, refit the cap **2** and close the fuel flap **A** to avoid any water or foreign bodies from entering the system.

Always make sure that the cap **2**, the flap **A** and its perimeter remain clean and free of dust, mud, dirt, etc.

Petrol version

It is **essential** to use unleaded petrol. Using leaded petrol will damage the antipollution system and may lead to a loss of warranty.

Capacity of the fuel tank: 40 litres approximately.



Persistent smell of fuel

If you notice a persistent fuel odour you should:

- stop the vehicle as soon as traffic conditions allow it and switch off the ignition;
- switch on the hazard warning lights and ask your passengers to leave the vehicle and stay clear of the traffic.
- contact an authorised dealer.

RUNNING IN

Running in

For the first **1,000 km**, do not exceed 80 km/h in the highest gear.

You may only expect top performance from your vehicle after approximately **3,000 kms**.

3

Oil change frequency : Please refer to your vehicle's maintenance schedule.

NOTE : During the running in period, do not accelerate hard while the engine is still cold and do not let the engine to run in higher rpm.

Service intervals : refer to the Maintenance Schedule for your vehicle.



STARTING, STOPPING THE ENGINE

Ignition-starter switch on a vehicle with key

Stop and steering lock position **St**



To lock : remove the key and turn the steering wheel until the steering column locks.

To unlock : turn the key and the steering wheel slightly.

Accessories position **A**

When the ignition is switched off, any accessories (radio, etc.) will continue to function.

Ignition on position **M**

The ignition is switched on :

- the engine may be started.

Start position **D**

If the engine fails to start at the first attempt, turn the key back to home position before activating the starter again.

Release the key as soon as the engine starts.

i NOTE :

- Do not attempt to start/ crank the engine in running/ geared condition ;
- Do not attempt to crank the engine more than 5 times repeatedly, if the vehicle doesn't start. Wait for sometime and crank the engine. If the vehicle didn't start, contact the nearby authorised dealer ;

Starting the engine

In cold condition: switch on the ignition for several seconds **before** starting the engine, so that it is easier to start the engine.

Petrol injection

- Activate the starter **without pressing the accelerator**.
- Release the key as soon as the engine starts.



Once switching on the ignition, wait for three seconds then crank the engine.

Vehicles with an automated manual transmission → 103.

Stopping the engine

With the engine idling, turn the key back to "Stop" position **St**.

Special note

Depending on the vehicle, accessories (e.g. radio) stop working either when the engine is switched off or when the doors are locked.

STARTING, STOPPING THE ENGINE



Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY

Starting problems

To avoid damage, **do not keep trying to start the engine (by pushing or towing the vehicle) without having identified and corrected the cause of the fault.**

If the fault cannot be identified, do not continue to try and start the en-

gine, but contact an approved dealer.

The following operating conditions should be avoided :

- driving for long periods when the low fuel level warning light is lit.
- using leaded petrol.
- using fuel or lubrication additives which are not approved.

Operating faults such as :

- faulty ignition, running out of fuel or disconnected spark plugs resulting in the engine misfiring or cutting out when driving.
- loss of power.

may cause overheating, reducing efficiency **which may irreparably damage vehicle components and also the vehicle.**

If you notice any of the above operating faults, have the necessary repairs carried out as soon as possible by an approved dealer.

These faults may be avoided by regularly taking your vehicle to an approved Dealer at the intervals specified in the Maintenance Schedule.



Do not park the vehicle or run the engine in locations where combustible substances or materials such as grass or leaves can come into contact with the hot exhaust system.

Starting, stopping the engine - vehicle with card



44164

The card must be in detection zone **1**.


To start :

- vehicles with an automatic gearbox, place the lever in position **N**,

STARTING, STOPPING THE ENGINE

press brake pedal and press button **2**;

- vehicles with a manual gearbox, depress the brake or clutch pedal and press the button **2**. If a gear is engaged, the vehicle may only be started by depressing the clutch pedal.



Special features


- If one of starting conditions is not applied, the message "BRAKE + START" or "CLUTCH + START" or "Select **NEUTRAL**" is displayed on the instrument panel;

- in some cases, it will be necessary to move the steering wheel whilst pressing the start button **2** to help unlock the steering column ; the

message "TURN+ START" will warn you of this;

Starting with tail gate open in hands-free mode.

In this case, hands free card must not be located in the luggage compartment.




Accessories function

(switching on the ignition)

Once you have gained access to your vehicle, you may use some of its functions (radio, navigation, wipers, etc.).

To use the other functions, with the card in the passenger compartment,

press the **2** button without pressing the pedals.



Operating faults

In certain cases, the hands-free card may not work :

- when the card battery is drained, flat battery, etc.,
- near to appliances operating on the same frequency as the card (monitor, mobile phone, video game, etc.);
- vehicle located in a high electro-magnetic radiation zone.

The message, "**KEY NOT DETECTED**" appears on the instrument panel.

Press the brake or clutch pedal, then place the hands free card in contact with position **3** around 2 seconds.

STARTING, STOPPING THE ENGINE

Press **2** to start the vehicle, the message goes out.

3




Driver's responsibility when parking or stopping the vehicle

Never leave an animal, child or adult who is not self-sufficient alone in your vehicle, even for a short time.

They may pose a risk to themselves or to others by starting the engine, activating equipment such as the electric windows or locking the doors, for example.

Also, in hot and/or sunny weather, please remember that the temperature inside the passenger compartment increases very quickly.

RISK OF DEATH OR SERIOUS INJURY



Conditions for stopping the engine

The vehicle must be stationary, with the lever positioned in **N** for vehicles with an automatic gearbox.

With the card in the vehicle, press button **2** : the engine stops. The steering column is locked when the driver's door is opened or the vehicle is locked.

If the card is no longer in the passenger compartment when you try to switch the engine off, the message "PRESS HOLD START" appears on the instrument panel : press button **2** for longer than two seconds. If the card is no longer in the passenger compartment, make sure you can retrieve it before pressing and hold-

ing the button. Without the card, you will not be able to restart the vehicle.

With the engine switched off, any accessories being used (radio, etc.) will continue to function for approximately 10 minutes.

When the driver's door is opened, the accessories stop working.



When you leave your vehicle, especially if you have your card with you, check that the engine is completely switched off.



Do not park the vehicle or run the engine in locations where combustible substances or materials such as grass or leaves can come into contact with a hot exhaust system.


STARTING, STOPPING THE ENGINE



Never switch off the ignition before the vehicle has stopped completely. Once the engine has stopped, the brake servo, power-assisted steering, etc., and the passive safety devices such as the airbags and pretensioners will no longer operate.

GEAR LEVER, HAND BRAKE

Selecting reverse gear



(vehicle in stationary condition)

Vehicles with manual gearbox: refer to the grid on the gear lever knob **1**.

Depending on variants, pull the release knob **A** in upward direction and then engage the reverse gear. Shifting the reverse gear should not be done quickly. Wait for three seconds approximately and shift the reverse gear.

Vehicles with an automated manual transmission → 103.

The reversing lights will come on as soon as reverse gear is selected with the ignition on.

Handbrake



To release

Pull lever **3** up slightly, press button **2** and then lower the lever to the floor.

The red warning light on the instrument panel will come on and a sound if you are driving with an incorrectly released handbrake at speeds over 8 km/h (5 mph).

To apply

Pull lever **3** upwards and make sure the vehicle is immobilised.



An impact to the underside of the vehicle while manoeuvring (e.g. : striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. : deformation of an axle). To avoid any risk of accident, have your vehicle checked by an approved dealer.



Make sure that the handbrake is properly released when driving (red indicator light off), otherwise overheating, or even damage, may occur.



Depending on the gradient and/or vehicle load, it may be necessary when stationary to apply the handbrake by at least a further two notches and engage a gear (1st gear or reverse gear).

SPECIAL FEATURES OF PETROL VERSIONS

The following operating conditions :

- driving for long periods when the low fuel level warning light is lit ;
- using leaded petrol ;
- using fuel or lubrication additives which are not approved.

Or operating faults such as :

- faulty ignition system, running out of fuel or disconnected spark plugs resulting in the engine misfiring or cutting out when driving ;
- loss of power.

as they may cause the catalytic converter to overheat and thus reduce its efficiency, **or damage it irreparably**

and cause heat damage to the vehicle.

If you notice any of the above operating faults, have the necessary repairs carried out as soon as possible by an approved Dealer.

These faults may be avoided by regularly taking your vehicle to an approved

Dealer at the intervals specified in the

Maintenance document.

Starting problems


To avoid damaging the catalytic converter, **do not keep** trying to start the

engine (using the start button, or by pushing or towing the vehicle) **without**

having identified and corrected the starting fault.

If the fault cannot be identified, do not

keep trying to start the engine, but contact an approved dealer.



Do not park the vehicle or run the engine in locations where combustible substances or materials such as grass or leaves can come into contact with the hot exhaust system.



DRIVER CORRECTION DEVICES, AIDS

Depending on the vehicle, this is composed of:

- **the ABS (anti-lock braking system);**
- **the emergency brake assist;**
- **electronic stability program ESC with understeer control and traction control.**

3



These functions are an additional aid in the event of critical driving conditions, enabling the vehicle behaviour to be adapted to suit the driving conditions. However, the functions do not take the place of the driver. They do not increase the vehicle's limits and should not encourage you to drive more quickly. Therefore, they can under no circumstances replace the vigilance or responsibility of the driver when manoeuvring the vehicle (the driver must always be ready for sudden incidents which may occur when driving).

ABS (anti-lock braking system)

Under heavy braking, the ABS prevents the wheels from locking, allowing the stopping distance to be managed and keeping control of the vehicle. Under these circumstances, the vehicle can be steered to avoid an obstacle whilst braking. In addition, this system can increase stopping distances, particularly on roads with low surface grip (wet ground etc.).

You will feel a pulsation through the brake pedal each time the system is activated. The ABS does not in any way improve the vehicle's physical performance relating to the road surface and roadholding. It is still essential to follow the rules of good driving practice (such as driving at a safe






In an emergency, apply firm and continuous pressure to the brake pedal. There is no need to pump it repeatedly. The ABS will modulate the force applied in the braking system.



Under some driving or climatic conditions, occasional brake squeaks, squeals or other noises may be heard. Occasional brake noise during light to moderate stops is normal and does not affect the function or performance of the brake system.

Operating faults

- If the  warning light on the instrument panel comes on while you are driving, **the brakes will still work normally without ABS;**
- If the  and  warning lights on the instrument panel come on while you are driving, **there is a fault in the braking system.**

In both cases, consult an approved Dealer.

Emergency brake assist with electronic brake distribution

(depending on the vehicle)

This system supplements the ABS and helps reduce vehicle stopping distances.

DRIVER CORRECTION DEVICES, AIDS

Operating principle

The system is for detecting an emergency braking situation. In this case, the braking assistance immediately develops maximum power and may trigger ABS regulation.

ABS braking is maintained as long as the brake pedal is applied.



Your braking systems are partially operational. However, it is **dangerous to brake suddenly** and it is essential to stop immediately, as soon as traffic conditions allow. Contact an approved dealer.

Electronic stability program ESC with understeer control and traction control



Electronic Stability Program ESC (depending on the vehicle)

This system helps you to keep control of the vehicle in critical driving conditions (avoiding an obstacle, loss of grip on a bend, etc.).

Understeer control

This system optimises the action of the ESC in the case of pronounced understeering (loss of front axle road holding).

Traction control

This system helps to limit wheelspin of the drive wheels and to control

the vehicle when pulling away accelerating or decelerating.

Deactivating the ESC function

In some situations (driving on very wet ground : snow, mud, etc. or driving with snow chains fitted), the system may reduce the engine output to limit wheelspin.

If this is not required, it is possible to deactivate the function by pressing switch **1**.

The warning light  on the instrument panel comes on to warn you of this.

If you deactivate this function, the traction control system will also be deactivated.

With the Electronic Stability Program ESC with understeer control and traction control providing additional safety, you are advised not to drive with the function disabled. Correct this as soon as possible by pressing the switch **1** again.

Note : The function is automatically reactivated when the ignition is switched on, or when the speed exceeds (30 mph) 50 km/h.


Operating principle

3


DRIVER CORRECTION DEVICES, AIDS


A sensor in the steering wheel detects the direction selected by the driver.

Other sensors throughout the vehicle measure the actual direction. The system compares driver input to the actual trajectory of the vehicle and corrects the trajectory if necessary by controlling the braking of certain wheels and/or engine power. In the event that the system is en-

gaged, the indicator light  flashes on the instrument panel.

Operating faults

When the system detects an operating fault the warning lights 

and  appear on the instrument panel.

In this case, the Electronic Stability Program ESC with understeer control and traction control are deactivated.

Please consult an authorised dealer if these warning lights remain displayed on the instrument panel after the ignition is switched off and on again

Hill start assistance

This function assists the driver when starting on hills. It prevents the vehicle from rolling forwards or backwards by automatically applying the brakes when the driver lifts their foot off the brake pedal to depress the accelerator pedal.

System operation

It only operates when the gear selector is in a position other than neutral (other than **N**) and the vehicle is completely stationary (brake pedal depressed).

The system holds the vehicle for approximately **2 seconds**. The brakes are then gradually released (the vehicle will move according to the slope).



The hill start assistance system cannot completely prevent the vehicle from rolling

backwards in all situations (extremely steep gradients, etc.).

In all cases, the driver may depress the brake pedal to prevent the vehicle from rolling forwards or backwards.

The hill start assistance function should not be used for prolonged stops : use the brake pedal.

This function is not designed to immobilise the vehicle permanently.

If necessary, use the brake pedal to stop the vehicle.

The driver must remain particularly vigilant when driving on slippery or low-grip surfaces and/or on hills.

Risk of serious injury.

TAKE A BREAK REMINDER

The take a break reminder lets you set a reminder to take a break **1**, when the driver tends to drive for long without a break which would cause drowsiness otherwise stressed driving leading to high chances of accident.

It takes into account indicators such as:

- Travel Distance
- Travel Time
- Customer Rest Time



65867




This function is an additional driving aid in case of risk of fatigue or impaired attention.

The function does not take the place of the driver. Under no circumstances should this function replace the driver's care or responsibility whilst driving.

Switching ON / OFF Function:

When the vehicle stationary,




65110

- Press switch **2** as many times as necessary to position yourself on the setting tab.

- By pressing the switch **3** "Take A Break" function will appear on the display.
- Press the switch **4** **OK** to ON/OFF the "Take A Break" function.


65868

3



TAKE A BREAK REMINDER

3



65869



65870



65871

65872



- Once switching ON the "Take A Break" function and it will enter to the Feature options.
- By pressing the switch **3** "SET DISTANCE" function will appear on the display.
- By pressing the switch **4**, it will enter to the set distance KM selection.
- Customer can SET driving distance (150km/ 200km/ 250km) by using downwards and upwards switch **3**.
- Press the switch **4** OK to select the driving distance km.

SET Time:


- Once switching ON the "Take A Break" function and it will enter to the Feature options.
- By pressing the switch **3** "SET Time" function will appear on the display.
- By pressing the switch **4**, it will enter to the set time mins selection.
- Customer can SET driving time (90Mins/ 120Mins/ 150Mins) by using downwards and upwards switch **3**.
- Press the switch **4** OK to select the driving time mins.

SET Rest Time:

Operation:

SET Distance:

TAKE A BREAK REMINDER



- Once switching ON the "Take A Break" function and it will enter to the Feature options.
- By pressing the switch **3** "SET Reset Time" function will appear on the display.
- By pressing the switch **4**, it will enter to the set reset time Mins selection.
- Customer can SET rest time (5Mins/10Mins/15Mins) by using downwards and upwards switch.
- Press the switch **4 OK** to select the Rest time.
- If any one of the setting parameters (Distance/Time) threshold value meets, by the time "TAKE A BREAK" message displayed on the instrument panel continue for 30 seconds

(alert will disappear if user acknowledge with in 30 seconds or vehicle speed reaches 0 km/h (0 mph)) and with 3 seconds chime.

- It is advisable to stop as soon as possible for a selected break time.
- If user not taken break after alert message, this message will reappear in every 30 minutes or 50km.
- The Take A Break warning continuously monitors the parameters and can provide several warnings per journey.
- The system resets every time the engine is started.

The system resets when if exceeds the rest time based on following conditions.

- Engine idle condition, Vehicle speed 0 km/h (0 mph)
- Engine OFF.

- i** - User need to ON the function and by default the function is OFF state
- Once the function ON, Remains ON until OFF by user

DRIVING ADVICE AND ECO DRIVING

Fuel consumption is accredited in accordance with a standard regulatory method. Identical for all manufacturers, this enables vehicles to be compared with one another.

3

Consumption in real time depends on vehicle usage conditions, the equipment fitted and the user's driving style. To optimise fuel consumption, please refer to the following advice.



Depending on the vehicle, you have different functions to help you reduce your fuel consumption:

- the rev counter;
- the gear change indicator;

On the multimedia screen (for more information, see the multimedia system user manual):

- scores based on your driving style;
- advice for ECO driving;
- the journey record and eco-driving advice via the multimedia screen;

Gear change indicator 1




Depending on the vehicle, to obtain optimum consumption levels, a warning light on the instrument panel lets you know the best time to move up or down a gear:



If you regularly follow this indicator, you will reduce your vehicle's fuel consumption.

On the multimedia screen



Journey record

Once the engine is switched off,

DRIVING ADVICE AND ECO DRIVING

From the multimedia screen 2 enabling you to view information on your last journey.

This indicates:

- Trip Report;
- ECO Scoring;
- ECO Coaching.

An overall rating from 0 to 100 is displayed to let you assess your eco driving performance.


The higher the rating, the lower the fuel consumption.

Eco advice is given to help improve your performance.

With your favourite journeys saved, you can compare your performance between trips and the performance of other vehicle users.

Please refer to the multimedia instructions for further information.

Driving advice, Eco-driving



Behaviour

- Drive carefully until the engine reaches its normal operating temperature, rather than let it warm up while the vehicle is stationary;
- High speeds significantly affect the vehicle's fuel consumption;

Examples (at a steady speed):

- reducing the speed from 130 km/h (80 mph) to 110 km/h (68 mph) approximately saves up to 20% of fuel approximately;
- reducing the speed from 90 km/h (56 mph) to 80 km/h (50 mph) approximately saves

up to 10% of fuel approximately.

- Dynamic driving involving heavy and frequent acceleration and braking is expensive on fuel in comparison to the time saved;
- Do not over rev the engine in the intermediate gears. You should always use the highest gear possible;
- Avoid sudden acceleration;
- Brake as little as possible. If you anticipate an obstacle or bend in advance, you may then simply release the accelerator pedal;
- Do not try to maintain the same speed up a hill, accelerate no more than you would on level ground. Keep your foot in the same position on the accelerator pedal;
- Double declutching and accelerating before switching off the engine are unnecessary in modern vehicles;
- On versions with an sequential gearbox, it is preferable to keep the gear lever in position **D**;
- Bad weather, flooded roads:



Do not drive through water if it is higher than the lower edge of the wheel rim.

DRIVING ADVICE AND ECO DRIVING



Driver obstruction


On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.

There is a risk of wedging the pedals.


Heating levels

It is normal to notice an increase in the vehicle's fuel consumption when using the heating (particularly when the outside temperature drops below zero) or air conditioning.

Tyres



- An underinflated tyre increases fuel consumption;
- To optimise fuel consumption, set the highest speed tyre pressure or the recommended pressure indicated on the edge of the driver's door → 142;
- The use of non-recommended tyres can increase fuel consumption.



Advice on use

- Electricity is fuel – switch off all the electrical components which are not really needed. **However** (safety first), keep your lights on when the visibility is bad ("see and be seen");
- Use the air vents. Driving with the windows open at 100 km/h (62 mph) will increase fuel consumption by 4% approximately;
- Never fill the fuel tank right to the brim to avoid overflow;
- **On vehicles equipped with non-automatic air conditioning**, switch off the air conditioning when it is not required.

DRIVING ADVICE AND ECO DRIVING

Advice for reducing consumption and helping to preserve the environment:

If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

- Do not leave an empty roof rack fitted to the vehicle;
- Avoid using the vehicle for "door-to-door" calls (short journeys with long waits in between) because in such conditions the engine never reaches its optimal operating temperature.

MAINTENANCE AND ANTIPOLLUTION ADVICE

3

Your vehicle complies with criteria for recycling and recovering vehicles at the end of their service life, which entered into force in 2015.

Some of the parts on your vehicle have been designed to be recycled later. These parts are easily removable in order to be collected and reprocessed in recycling networks.

Furthermore, by virtue of its design, moderate fuel consumption and initial settings, your vehicle also conforms to current anti-pollution regulations. The manufacturer is actively striving to reduce pollutant exhaust gas emissions and to save energy. However, the fuel consumption of your vehicle and the level of pollutant exhaust gas emissions are also your responsibility. Ensure that it is maintained and used correctly.

Maintenance

It is important to remember that failure to respect anti-pollution regulations could lead to legal action being taken against the vehicle owner.

In addition, replacing engine, fuel supply system and exhaust components with parts other than those originally recommended by the manufacturer may alter your vehicle

so that it no longer complies with anti-pollution regulations.

Have your vehicle adjusted and checked by an authorised dealer, in accordance with the instructions given in your maintenance schedule : they will have all the equipment necessary for ensuring that your vehicle is maintained to its original standard.

Engine adjustments

- **Spark plugs** : for optimum conditions of use, output and performance the specifications laid down by our design department must be strictly applied. If the spark plugs have to be changed, use the make, type and gap specified for your vehicle's engine. Contact an authorised dealer for this.
- **Air filter, fuel filter** : a choked element will reduce efficiency. It must be replaced.
- **Ignition and idle speed** : no adjustment is needed.

Exhaust gas monitoring system

The exhaust gas monitoring system will detect any operating faults in the vehicle's antipollution system.

If this system malfunctions, toxic substances may be released into the atmosphere or damage may occur.



This warning light on the instrument panel will indicate if there are any faults in the system :

This lights up when the ignition is switched on and goes out when the engine is started.

- If it lights up continuously, consult an approved dealer as soon as possible ;
- if it flashes, reduce the engine speed until the light stops flashing. Contact an authorised dealer as soon as possible.

ENVIRONMENT

Your vehicle has been designed with respect for the **environment** in mind for its entire service life : during production, use and at the end of its life.

This commitment is illustrated by the manufacturer eco² signature.

Manufacture

Your vehicle has been manufactured at a factory which complies with a policy to reduce the environmental impact on the surrounding areas (reduction of water and energy consumption, visual and noise pollution, atmospheric emissions and waste water ; sorting and reusing waste).

Emissions

For the usage phase, your vehicle was designed to emit fewer greenhouse gases (CO₂) and therefore to consume less fuel.

Our vehicles are also equipped with a particle filter system including a catalytic converter, an oxygen sensor and an active carbon filter (the latter prevents vapour from the fuel tank being released into the open air).

Please make your own contribution towards protecting the environment too

- Worn parts replaced in the course of routine vehicle maintenance (vehicle battery, oil filter, air filter, batteries, etc.) and oil containers (empty or filled with used oil) must be disposed of through specialist organisations.
- In all cases, comply with local legislation.

Recycling

Your vehicle is at least 85% recyclable and at least 95% recoverable.

To achieve these objectives, many of the vehicle components have been designed to enable them to be recycled. The materials and structures have been carefully designed to allow these components to be easily removed and reprocessed by specialist companies.

In order to preserve raw material resources, this vehicle incorporates numerous parts made from recycled plastics or renewable materials (vegetable or animal-derived materials such as cotton or wool).

TYRE PRESSURE MONITORING SYSTEM


3



59163

Operating principle

When the ignition switch is in ON position, the low tyre pressure warning light illuminates and then turned OFF, This indicates that the low tyre pressure warning system is operational.

Warning light  1 comes ON to alert the driver in the event of insufficient pressure (deflated wheel, punctured tyre, malfunction, etc.)

Low tyre pressure warning

If the vehicle is being driven with low tyre pressure  1 will illuminate.

When the low pressure warning light illuminates you should stop and ad-

just the tyre pressure to the recommended COLD tyre pressure. The low tyre pressure warning light doesn't automatically turned off when the tyre pressure is adjusted. After the tyre is inflated with the recommended pressure, the vehicle must be driven at speeds above 25 km/h (16 mph) to activate the Tyre pressure monitoring system and turn off the low tyre pressure warning light.

TPMS Malfunction :



65674

If the TPMS is not functioning properly the low tyre pressure warning light no 1 will flash for approximately 1 minute when the ignition switch is placed ON position. The light will remains ON after the 1 Minute, along

with the electrical warning tell tale or warning light malfunction tell tale no 2.

Operating conditions

In the following situations, the system risk coming into action late or not functioning correctly :

- system not reset after reinflation or any operation on the wheels ;
- system badly reset : different inflation pressures from the recommended pressures ;
- significant change in load or distribution of load on one side of the vehicle ;
- sporty driving with strong acceleration ;
- driving on snowy or slippery surface
- driving with snow chains ;
- fitting a single new tyre ;
- use of tyres not approved by the network ;

TYRE PRESSURE MONITORING SYSTEM



This function is an additional driving aid. The function does not take the place of the driver. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. Check the tyre pressures, including the emergency spare wheel, once a month.

Resetting the standard level for the tyre pressures

It must be carried out **while the vehicle is stopped** :

- after each reinflation or readjustment of the pressure of one of the tyres ;
- when the standard tyre pressure needs to be changed to adapt to usage conditions (empty, carrying a load, motorway driving, etc.) ;
- after changing a wheel ;
- after using the tyre inflation kit ;
- after switching the wheels of the same axle (you must not switch between the front and rear wheels).

It should always be done after checking the tyre pressure of all four tyres when cold.





Resetting procedure

Ignition on, **vehicle stationary**:

- press button **B** briefly several times to select the function " SET TYRE PRESSURE " is displayed ON the Instrument panel.


- press and hold (around 3 seconds) button **B** to start initialisation. If the

"SET  " warning light flashes or text message on the Instrument panel "TPMS ONGOING " for approximately 5 seconds accompanied by a constant illumination of the SET

 warning light, this indicates that the request for reinitialisation of the tyre pressure reference value has been correctly registered.


Reinitialisation is carried out after a few minutes' driving.

Resetting procedure (depending on vehicle)



Ignition on, **vehicle stationary**:

- press button **A** briefly several times to select the function " TYRE PRESSURE SET " is displayed ON the Instrument panel.
- press and hold OK switch **B** (around 3 seconds) to start initialization. Then confirm " RESET " tyre pressure message will appear. Select OK to reset the tyre pressure. If

 warning light along with

 are turned off. This indi-

TYRE PRESSURE MONITORING SYSTEM

icates that the request for re-initialization of the tyre pressure reference value has been correctly registered.

Readjustment of tyre pressures

3



59163

The tyre pressure must be adjusted when the tyres are cold

If the tyre pressure cannot be checked when the tyres are **cold**, the **recommended pressures must be increased by 0.2 to 0.3 bar (3 PSI)**.

Never deflate a hot tyre.

After each reinflation or readjustment of the tyre pressure, launch the reinitialisation of the tyre pressure reference value.

Inflate tyres and reset




65874

If  1 warning light comes ON

along with  or  2 warning light is displayed in Red,

This indicates that at least one tyre is flat or punctured. In the event of a flat tyre, inflate the relevant tyre. In the event of a puncture, change the tyre or consult an authorised dealer. It is not recommended to drive the vehicle if a tyre is punctured. This may cause tyre to damage → 147.

Warning light  1 goes out after launching the reset of the tyre pressure reference value.

Replacing wheels/tyres

Only use equipment approved by the network, otherwise the system risks late activation or incorrect operation.

After each change of wheel/tyre, readjust the tyre pressure and launch the reinitialisation of the tyre pressure reference value.

Emergency spare wheel

If the vehicle is equipped with an emergency spare wheel, it will not have a sensor.

when a spare tyre is mounted or wheel is replaced, the TPMS will not function and the low tyre pressure warning light will flash for approximately one minute. The light remains on after one minute. contact your authorised dealer as soon as possible for tyre replacement.

Tyre repair product and inflation kit

As the valves are specifically designed, only use equipment approved by the network.

System to be checked

Warning light  1 flashes for several seconds, then stays ON. Puncture


 illuminates as red colour

continuously or  illuminates as red colour continuously. This indi-

TYRE PRESSURE MONITORING SYSTEM

Indicates that a tyre is concerned is punctured or severely under inflated. Replace the tyre if it is punctured.

- Sensor Failure  Illuminates

and turned OFF or  Illuminates continuously as Orange colour. This indicates a system fault. Please consult an authorised dealer.

System unavailable

Warning light  flashes for several seconds, then stays ON.




TYRE PRESSURE MONITORING SYSTEM

Tyre pressure faults



The table on the following page lists the warning messages which appear on the instrument panel when the system detects a tyre pressure fault.

The information on the instrument panel signals any potential tyre pressure faults (e.g. deflated or punctured tyre).

3

| Indicator lights | Messages | Text warning in cluster | Readings |
|---|----------------------|--|--|
|  | Adjust Tyre Pressure | RR TYRE PR.LOW RL TYRE PR.LOW FR TYRE PR.LOW FL TYRE PR.LOW | When the tyre pressure loss warning is displayed in yellow. This indicates that tyre under-inflation has been detected. Check and adjust the pressure of the four tyres then reset the system. |
|  +  | Puncture | RR TYRE PUNCTURE RL TYRE PUNCTURE FR TYRE PUNCTURE FL TYRE PUNCTURE | When the tyre pressure loss warning is displayed in yellow and Warning light malfunction is displayed in Red. This indicates that the tyre concerned is punctured or severely under inflated. Adjust the pressure of the four tyres while cold and reset the system if the tyre is deflated. Replace the tyre (or have it replaced) if it is punctured. |




TYRE PRESSURE MONITORING SYSTEM

| Indicator lights | Messages | Text warning in cluster | Readings |
|--|-----------------------------|--|---|
|  +  | Check Tyre Pressure Sensors | CHECK RR TPMS CHECK RL TPMS CHECK FR TPMS CHECK FL TPMS | When the tyre pressure loss warning and Warning light malfunction are blinking in Yellow for 70 second. After 70 second approx. tyre pressure loss warning permanently ON & warning light malfunction switch off. This indicates the sensor is faulty. Consult an approved dealer. |

3





(depending on vehicle)

The information on the instrument panel signals any potential tyre pressure faults (e.g. deflated or punctured tyre).

| Indicator lights | Messages | Text warning in cluster | Readings |
|--|----------------------|---|--|
|  +  | Adjust Tyre Pressure |  ADJUST TYRE PRESSURE | When the tyre pressure loss warning & service warning light displayed in yellow. This indicates that tyre under-inflation has been detected. Check and adjust the pressure of the four tyres or corresponding tyres then reset the system. |

TYRE PRESSURE MONITORING SYSTEM

3

| Indicator lights | Messages | Text warning in cluster | Readings |
|---|-----------------------------|---|---|
|  | Puncture |  <p>PUNCTURE</p> | <p>When the tyre pressure loss warning is displayed in Yellow and STOP Warning light malfunction is displayed in Red (Audible warning for approx. 10 sec).</p> <p>This indicates that the tyre concerned is punctured or severely under inflated. Adjust the pressure of the four tyres while cold and reset the system if the tyre is deflated. Replace the tyre (or have it replaced) if it is punctured.</p> |
|  | Check Tyre Pressure Sensors |  <p>CHECK TYRE PRESSURE SENSOR</p> | <p>When the tyre pressure loss warning blinking in Yellow for 70 second and service warning light displayed in yellow.</p> <p>After 70 second approx. tyre pressure loss warning permanently ON & warning light malfunction switch off. This indicates the sensor is faulty. Consult an approved dealer.</p> |


AUTOMATED MANUAL TRANSMISSION

Gear Shifter 1



44074

Gear shift pattern




This allows you to engage forward gear, reverse and neutral.



For safety reasons, do not switch off the ignition before the vehicle has come to a complete standstill.

- (see the marking on the lever)
+ : Manually moving up a gear
- : Manually moving down a gear
M : manual mode
D : automatic mode
N : neutral
R : reverse

Instrument panel Display



36131

36149

3

- 2** : automatic mode.
3 : brake pedal press indicator light.
4 : current gear display.
The current gear (1, 2..., 5, or D, N, R) is indicated on the display **4** on the instrument panel. In automatic mode, A and the engaged gear are displayed.

Operation

Switch on the ignition.
The display on the instrument panel switches on.

AUTOMATED MANUAL TRANSMISSION

If neutral (**N**) is displayed, start the engine but do not press the accelerator.

If any gear other than neutral is engaged, **N** flashes on the display; press the brake pedal and place the lever in position **N**. Start the engine.

NB: Do not attempt to start the engine by pushing the vehicle if the battery is flat (the display remains OFF when the ignition is switched ON).

Under certain conditions, the engine starter may take some time. Keep the key in the starting position.

3




Exactly like a vehicle equipped with a manual gearbox, a vehicle equipped with a sequential gearbox is unable to prevent the vehicle from rolling on a slope if the handbrake is not applied or the brake pedal constantly not pressed. The vehicle can be in stationary place on an incline for two seconds (Giving Driver enough time to take his foot off the brake & press the accelerator)



Once the vehicle is switched to ignition ON position, the gearbox initializes. This produces a light sound. This is normal. Crank the engine after three seconds.

Starting



36131

Moving forwards (starting in neutral)

The gear display shows Neutral

With the brake pedal pressed, position the selector lever to **D**. The letter **A (Automatic)** appears on the cluster.

Release the brake pedal :

- The engine's idle speed is sufficient for parking manoeuvres.
- Accelerate gently to move forwards.



Start the engine, wait for three seconds before selecting D/R gears. Avoid shifting reverse gear immediately after starting the engine.

Reverse gear (from neutral, with the vehicle stationary)

With the brake pedal pressed, position the selector lever to **R**. The letter **R** appears on the display.

Release the brake pedal:

- The engine's idle speed is sufficient for parking manoeuvres.
- Accelerate gently to reverse.

There is a beep when reverse gear is engaged.

You may shift from reverse gear to a forwards gear by pushing the lever to **D** once the vehicle is stationary.

Note : When the vehicle is stationary, you must depress the brake pedal to engage a gear. Otherwise, warning

light  will come on.

AUTOMATED MANUAL TRANSMISSION



Avoid selecting D/R mode after switching off the engine.

If reverse gear not engaged properly, once the gear shifted from "N" to "R" position. Then the system will retry to shifting automatically. This will take some time, noise may be heard from gears. This however does not indicate any malfunction.

If still reverse gear not working, and warning buzzer sound along with "CHECK AUTO GEARBOX" and depending on the vehicle "CHECK GEARBOX" message appears on the cluster, then follow below steps:

With the vehicle stationary,

Pressing the brake pedal, shift the gear shifter lever:

- shift towards "N" position;

and

- again, shift towards "R" position.

Now, the reverse gear engaged. once brake pedal released then the vehicle will move in reverse direction.

If any warning light/ message appears in the instrument panel, please contact an approved dealer.

Creeping

It is a function that enables the vehicle to move slowly without pressing accelerator pedal. Follow the steps:

- Start the engine as instructed in "Starting the engine" section.
- With brake pedal pressed, shift the lever to D position.
- Release the parking brake and brake pedal to activate creeping.

Driving in manual mode

This mode can be activated at any time when driving by pushing the lever to position M.

To shift up a gear, simply push the selector lever backwards without necessarily releasing the accelerator.

To shift down a gear, simply push the selector lever forwards without necessarily releasing the accelerator.

The system will not tolerate a series of up or down changes that cause the engine to underrev or overrev.

By pushing the lever backwards twice, you can move up two gears at a time (except if under-revving). By pushing the lever forwards twice, you can move down two gears at a time (except if over-revving).

When decelerating with the foot off the pedal, the gears will automatically drop to the low engine speed limit to avoid stalling. The vehicle may be kept stationary (stop, red light etc.) by depressing the brake pedal without shifting into neutral N.

The vehicle will move off again :

- either slowly, if you release the brake without accelerating (e.g. when in a traffic jam),
- or quickly, if you release the brake and accelerate.

Note : Neutral N may only be selected when the vehicle is being driven or is stationary or without touching the brake pedal.

If the engine speed is too high or too low, the system will choose the optimum gear.

Manual mode can be deactivated and reactivated at any time with the engine running by moving the lever to position D and respectively to M.

Driving in automatic mode

Each time the ignition is switched on, starting in neutral, shift the lever to D with brake pedal pressed condition to be able to shift directly to automatic mode.

The letter A appears on the display. The vehicle is controlled using the

AUTOMATED MANUAL TRANSMISSION

accelerator and the brake. Gears will change automatically at the correct moment and at a suitable engine speed because automatic mode takes into consideration the road surface and the chosen driving style.

3

Note:

Automatic mode takes account of:

- the position and speed of pressing the accelerator pedal to assess driving style and select the optimum gear,
- the position and speed of pressing the brake pedal to start engine braking in preparation for a downshift.

If the engine is being overrevved or underrevved, the system will select the optimal gear.

When stopped at traffic lights, with the gear engaged, you can keep the vehicle stationary by pressing the brake pedal without changing to neutral N.

The vehicle will move off again:

- either slowly, if you release the brake (Creeping) without accelerating (e.g. when in a traffic jam),
- or quickly, if you release the brake and accelerate.

Economical driving

When driving, always leave the lever in position D, keeping the accelera-

tor pedal lightly pressed to ensure automatic gear changes at a lower engine speed.

It is recommended to shift to Manual mode from Auto mode with most adopted gear, to have quick acceleration during overtaking.

Accelerating and overtaking

- slowly press the accelerator pedal to accelerate gradually,
- **to obtain maximum vehicle performance regardless of the mode selected (automatic or manual), quickly press the accelerator pedal beyond the kickdown point.**

The speed with which you press the pedal will allow you to upshift according to the vehicle's capabilities.

Depending on the variant, if the warning message, "GEARBOX OVERHEAT" appears on the cluster when driving, it means the clutch gets overheated and creeping gets deactivated.

To avoid getting the message,

- use parking brake to move the vehicle in slope;
- do not press the brake pedal/accelerator pedal simultaneously for long time;
- do not keep vehicle in standstill in slope using accelerator pedal;

If you are not doing any of above mentioned manoeuvres but the warning message, "GEARBOX OVERHEAT" appears, then contact your dealer

PARKING DISTANCE CONTROL


Operating principle

Ultrasonic sensors, fitted in the vehicle's rear bumper, measure the distance between the vehicle and an obstacle when reversing.

This measurement is indicated by beeps which become more frequent the closer you come to the obstacle, until they become a continuous beep when the vehicle is approximately 35 centimetres from the obstacle.


There is a beep when reverse gear is engaged. If the beep sounds for a long time (3 seconds), this signals an operating fault.

NB : ensure that the ultrasonic sensors are not obscured (by dirt, mud, snow, etc.).



Note :

Depending on the vehicle, the screen **1** shows the vehicle surroundings alongside the beeps.



3

Operation :

When reverse gear is selected, most objects which are less than approximately 1.20 metres from the rear of the vehicle are detected, a beep sounds and, depending on the vehicle, the display **1** comes on.

Operating faults

When the system detects an operating fault, there will be a three-second continuous beep as a warning. Please consult an authorised dealer.

PARKING DISTANCE CONTROL



This function is an additional aid that indicates the distance between the vehicle and an obstacle whilst reversing, using sound signals. Under no circumstances should it replace the driver's care or responsibility whilst reversing. The driver should always be ready for sudden incidents while driving : always ensure that there are no small, narrow moving obstacles (such as a child, animal, pushchair, bicycle, stone, post, etc.) in the blind spot when manoeuvring.



An impact to the underside of the vehicle while manoeuvring (e.g. : striking a post, raised kerb or other street furniture) may result in damage to the vehicle (e.g. : deformation of an axle). To avoid any risk of accident, have your vehicle checked by an approved dealer.


REVERSING CAMERA

Operation



Depending on the variants, when using reverse gear, the camera **1** sends a view of the area behind the vehicle to the multimedia display **2** together with a static guide line.


This system is used with the aid of a fixed distance gauge. When the red zone is reached, stop the vehicle.



Note: make sure that the reversing camera is not obscured (by dirt, mud, snow, etc.).



This function is an additional aid. It cannot, therefore, under any circumstances replace the vigilance or the responsibility of the driver. The driver should always pay attention to sudden incidents during driving: always ensure that there are no moving obstacles (such as a child, animal, pram, bicycle, etc.) or small, narrow objects such as stones or posts in your path when manoeuvring.



REVERSING CAMERA

Static guide line 3 :

The static guide line **3** has coloured markers **A**, **B** and **C** showing the distance behind the vehicle :

- **A** (red) approximately 30 centimetres from the vehicle ;
- **B** (yellow) approximately 70 centimetres from the vehicle ;
- **C** (green) approximately 150 centimetres from the vehicle.

3



The screen shows a reverse image.

The frames are a representation projected onto flat ground ; this information must not be taken into account when superimposed on a vertical object or an object on the ground. Objects which appear on the edge of the screen may be deformed.


In very bright light (snow, vehicle in sunshine etc.), the camera vision may be adversely affected.

This gauge remains fixed and indicates the vehicle trajectory if the wheels are in line with the vehicle.



AIR VENTS, AIR OUTLETS

Air outlets



44204

4

AIR VENTS, AIR OUTLETS

1. Left side air vents
2. Windscreen demisting vents
3. Centre air vents
4. Right side vents
5. Control panel
6. Driver footwell outlets
7. Front passenger footwell outlets

4

AIR VENTS, AIR OUTLETS

Air flow



Lateral Air vents(Left and Right)

- To move the front vanes up/down, move the centre knob **8** upwards/downwards;
- To open/close the side vanes (inside the centre knob), move the centre knob **8** towards outside/inner-side respectively;

Air vents are having rear fixation. To service air vents, complete Instrument panel assembly had to be disassembled.

Centre Air Vents



(depends on the vehicle)

- To move the front vanes up/down, move the centre knob **9** upwards/downwards;
- To open/close the centre vanes (inside the centre knob), move the centre knob **9** towards towards outside/innerside respectively;

Air vents are having rear fixation. To service air vents, complete Instrument panel assembly had to be disassembled.

Rear Air Vents



Depending on variants, rear air vents **10** is fitted on the second row pillar trim.

AIR VENTS, AIR OUTLETS

Rear roof Air Vents



4

Depending on variants, roof air vents **11** is fitted on the roof rear side of the vehicle.




Do not add anything to the vehicle's ventilation circuit (for example, to remove bad odours).

There is a risk of damage or of fire.



HEATING, VENTILATION, AIR CONDITIONING

Controls



The controls will depend on the vehicle equipment level.

1. Distribution of Air.

2. Adjusting the ventilation fan speed.

3. Switching passenger compartment to isolation mode / air recirculation mode.

4. Air temperature adjuster

5. Switching air conditioning on/off (if light gets ON, it indicates the air conditioning system is ON).

Information and advice on use → 116.

Adjusting the air temperature

Turn control **4** to obtain the desired temperature. The further towards the red the slide is, the higher the temperature will be.

Adjusting the ventilation fan speed.

Turn control **2** from 0 to 4. The further to the right it is positioned, the more air is blown into the passenger compartment. If you want to shut off the flow of air completely and stop the system, set control **2** to 0.

The system is deactivated : the ventilation speed for the passenger compartment air is zero (vehicle stationary), you can however still feel a slight flow of air when the vehicle is moving.



Leaving this control in position 0 for prolonged periods can lead to condensation forming on the side windows and windscreen and problems due to the use of non-renewed air in the passenger compartment.

Switching passenger compartment isolation mode/air recirculation mode on.

Bring lever **3** to position

Under these conditions, air is taken from the passenger compartment and is recirculated, with no air being taken from outside the vehicle.

Air recirculation is used to :

- to isolate the passenger compartment from the external atmosphere.
- to bring the passenger compartment to the desired temperature as quickly as possible.

Rapid demisting

- Turn control **4** on full hot position.
- Turn control **2** on max speed position 4.
- Turn control **1** to full defrost mode



- move slider knob **3** to fresh air mode.

Using the climate control increases the speed of demisting.

Information and advice on use : → 116

HEATING, VENTILATION, AIR CONDITIONING



Prolonged use of air recirculation can lead to condensation forming on the windscreen, and discomfort due to the use of non-renewed air in the passenger compartment.

You are therefore advised to pick-up external air as soon as the air recirculation function is no longer required, by sliding control **3** to the right.

Air conditioning: information and advice on use

Fuel consumption

You will normally notice an increase in fuel consumption (especially when driving in town) when the air conditioning is operating.

Advice for reducing consumption and helping to preserve the environment.

Drive with the air vents open and the windows closed.

If the vehicle has been parked in the sun, open the doors for a few moments to let the hot air escape before starting the engine.

Maintenance

Refer to the Maintenance Document for your vehicle for the inspection frequency.

Operating faults

As a general rule, contact your approved dealer in the event of an operating fault.

– Reduction in de-icing, demisting or air conditioning performance.

Contact an approved dealer.

– No cold air is being produced.

Check that the controls are set correctly and that the fuses are sound. Otherwise, switch off the system.

Presence of water under the vehicle


After prolonged use of the air conditioning system, it is normal for water to be present under the vehicle. This is caused by condensation.



Do not open the refrigerant fluid circuit. The fluid may damage eyes or skin.

WINDOWS

Electric window



Press/pull the switch to raise/lower the windows to the desired height (the rear windows do not open fully).

From the driver's seat, use


1 for driver side ;

2 and **4** for rear passenger side ;

3 for driver to prevent operation of rear electric windows. A confirmation message will display in the cluster ;

5 for front passenger side.

From the rear seats



Depending on the variants, use **6** to raise/lower the rear passenger windows to the desired height.

Manual window winders



Depending on the variants, turn handle **7** to lower or raise the window to the desired height.

One-touch mode

Depending on the vehicle, this mode works in addition to the operation of the electric windows described previously. It is only fitted to the driver's window. Briefly press or pull switch **1** fully : the window is fully lowered or raised. Pressing the switch again stops the window moving.

Note : If the driver's window detects resistance when closing (e.g. tree branch, etc.), it stops and then lowers again by a few centimetres.

WINDOWS



When closing the windows, ensure that no part of the body (arm, hand, etc.) is protruding from the vehicle.

Risk of serious injury.



Avoid resting any objects against a half-open window: there is a risk that the electric window could be damaged.

4



Driver's responsibility

Never leave your vehicle with the key or remote control in it, leaving a child, adult who is not self-sufficient or a pet inside, even for a short while.

They may pose a risk to themselves or to others by starting the engine or activating equipment (such as the gear lever or electric windows).


If any part of the body becomes trapped, reverse the direction of the window immediately by pressing the relevant switch.

Risk of serious injury.



INTERIOR LIGHTING

Front Courtesy light




This feature depends on the vehicle version.

1. Press switch to position

- **A** for switching **OFF** the light.
- **B** for auto-ON lighting, which activates when a door is opened and switches off when the doors have been closed correctly.
- **C** for switching **ON** the light.

Front Map reading light



This feature depends on the vehicle version.

2. Pressing switch provides :

- Continuous lighting ;
- no lighting.

Rear Courtesy light




This feature depends on the vehicle version.

3. Press switch to position

- **A** for switching **OFF** the light.
- **B** for auto-ON lighting, which activates when a door is opened and switches off when the doors have been closed correctly.
- **C** for switching **ON** the light.

SUN VISOR/GRAB HANDLE

Front sun visor




Lower the sun visor **1** over the windscreen or unclip it and turn it over the side window.

Courtesy mirrors

Depending on variants, it is fitted with courtesy mirrors **2**.


Rear Grab handle 2



This offers support and can be held when the vehicle is being driven, Do not use it for getting into or out of the vehicle.

PASSENGER COMPARTMENT STORAGE

Upper Glove Box




Depending on variant, Press **1** to open the upper glove box.

Lower Glove box


Pull handle **2** to open lower glove box.

Cooled Glovebox




Depending on the variant, opening/closing the valve **3** along the arrow direction will enable/disable the cooling inside glove box.

Centre console Storage 4



4

Cup Holder 5




PASSENGER COMPARTMENT STORAGE

4




Ensure that no hard, heavy or pointed objects are placed in the "open" storage compartments in such a way that they may fall onto passengers during sudden turning, braking or in the event of an accident.

Rear console cooled box 6



Depending on variant, vehicle is fitted with rear console cooled box. Gently pull the valve **A** and move along the arrow direction to enable the cooling inside the box.

Front door storage 7




They can hold 1 litre bottle.



Nothing should be placed on the floor area in front of the driver as such objects may slide under the pedal during braking manoeuvres, thus obstructing its use.


Rear door storage 8



They can hold 1litre bottle.


PASSENGER COMPARTMENT STORAGE

Third row armrest storage 9



Depending on variants, front seat storage available behind the front seat backrest.

Front seat storage 10




ACCESSORIES SOCKET

Accessories socket 1, 2

4




It is provided for connecting accessories approved by our technical department.



Connect accessories with a maximum power of 120 watts (12 V) only. When several accessory sockets are used at the same time, the total power of the connected accessories must not exceed 180 watts.
Fire hazard.

REAR SEATS

To slide the second row seat



- lift handle **1** to unlock and slide the seat front or back ;
- Release the handle once the seat is in desired position and ensure that the seat is locked.

To recline the second row seat back rest



- turn the knob **2** to recline the seat backrest.



When refitting the seatback, make sure it is correctly locked in place.


If seat covers are fitted, make sure these do not prevent the seatback latch from locking in. Make sure that the seat belts are positioned correctly. Check that the rear seat belts are positioned and operating correctly each time the rear seat is moved.

Never allow anyone to ride in the luggage area or on second row seat when it is in the fold-down position. Use of these areas by passengers without proper restraints could result in serious injury in an accident or sudden stop.


Properly secure all luggage to help prevent it from sliding or shifting. Do not place luggage higher than the backrest. When operating the backrest, be careful not to scratch or damage seat belts.

REAR SEATS

To tumble the second row backrest-left side seat




- lower the headrest;
- turn the knob **3** to fold the seat backrest;
- Fold/tumble will be done simultaneously as shown in illustration **A**;
- Ensure that tumble action is fully completed by holding the tumbled seat;
- repeat the above instructions in reverse manner to return the backrest and lock the seat to its original position.



i When returning the backrest, there is a clicking sound. It is because of one-touch mechanism.

i It is recommended to tumble the rear second row seat, with the headrest in lowered condition, to avoid breakage of head rest bezel.

i It is not permitted to drive the car while second row seat is in tumbled condition as it leads to damage to the passenger in the third row.




To remove the third row backrest

- Ensure the seatbelts are properly stored and lower the headrest fully;
- Pull knob **1** upwards and rotate the backrest forward to certain angle as shown in the illustration **A**;
- Lift the seat backrest slowly upwards in the same orientation to disassemble the seat backrest;

REAR SEATS

– Follow the same steps in reverse manner to assemble the seat backrest.

NOTE: Gap **3** between third row seat back and cushion will allow the customer to grab the seatback and removing them.




To remove the third row cushion

Follow the steps after removing the backrest;

- Pull the strap **2** and lift the cushion vertically to a certain angle as shown in illustration **B**;
- Lift the seat cushion upwards in the same orientation to disassemble the seat cushion. Ensure that the mounting brackets comes out completely from the floor on both ends;

– Follow the same steps in reverse manner to assemble the seat cushion



When refitting the seatback, make sure it is correctly locked in place.

If seat covers are fitted, make sure these do not prevent the seatback latch from locking in. Make sure that the seat belts are positioned correctly. Reposition the headrests.



Make sure that the seatback is correctly locked. If necessary, remove any obstacles behind the seats. Repeat the above until the seat is locked correctly.



It is not permitted to drive with one of the third row seats folded down if a passenger is in the other third row seat. Risk of injury



Do not attempt to remove the third row headrest when the tail gate is closed as it may break the tail gate glass.



Make sure the third row headrest is in lowered condition while closing the tail gate.

BOOT

To open

4



From the outside

Press **1** and lift the tail gate.

44117



Opening the tail gate manually from the inside

If it is impossible to unlock the tail-gate from outside, it can be done manually from inside ;

- access the luggage compartment by tilting the rear bench seatback(s) ;

- insert a pencil or similar object in recess **2** and slide the unit as shown in the illustration ;

- push the tail gate to open it.



The attaching of any carrying device (bike rack, luggage box etc) resting on the luggage compartment lid is prohibited. To install a carrying device on your vehicle, contact an authorised dealer.

LONGITUDINAL ROOF BARS



44082

If fitted on the vehicle, you can transport luggage or additional equipment (bike racks, ski racks, etc):

- on a roof rack;
- on transverse roof bars which must in turn be attached to roof bars fitted lengthways **1**;
- directly onto the longitudinal roof bars.

It is forbidden to fit longitudinal roof bars on vehicles which are not originally equipped/ not recommended by manufacturer.




For information on the range of equipment adapted to your vehicle, we advise you to consult an approved Dealer. Refer to the manufacturer's instructions for information on how to fit and operate the equipment. Please keep these instructions with the rest of the vehicle document.

Maximum permissible load on roof rack: refer to the information on "Weights" in Section 6.

MULTIMEDIA EQUIPMENT

4



The presence and location of this equipment depends on the vehicle's version and multimedia equipment.

1. Radio or navigation system.
2. Microphone.




- In all cases, it is very important to follow the manufacturer's instructions carefully.

- The specifications of the brackets and wires (available from our network) vary depending on the equipment level of your vehicle and the type of radio.

Consult your approved Dealer to find out the correct part number.

- No work may be carried out on the vehicle's electrical or radio circuits, except by approved Dealers: an incorrectly connected system may result in damage being caused to the electrical equipment and/or the components connected to it.

Hands-free telephone integrated control



On equipped vehicles, use microphone **2**.

If your vehicle is not fitted with an audio system, one can be fitted and locations have been provided for the radio **1**.

To install any equipment, please consult an authorised dealer.

Refer Multimedia manual for more details.

MULTIMEDIA EQUIPMENT




Using the telephone

We remind you of the need to conform to the legislation in force concerning the use of such equipment.




To use this equipment, consult the instructions for the equipment which should be kept with the other vehicle documentation.

Steering wheel controls



On equipped vehicles, use :

- **3** select the audio source.
- **4** Scroll to navigate the list with press function.
- **5** Volume decrease "-".
- **6** Volume increase "+".



- **7** Mute.
- **8** Answer the call/call attend.

BONNET

5




To open the bonnet, pull the knob **1**.

Unlocking the bonnet latch

To unlock, gently lift the bonnet and push tab **3** in the direction of arrow **A** to release the latch **2**.


Opening the bonnet

Lift the bonnet ; remove the Hood-Stay rod **4** from lock clip from the hood and place into the hole to hold the Hood open.



Do not press down on the bonnet : there is a risk that the bonnet may accidentally close.

Closing the bonnet



To close the bonnet again, remove the Hood-Stay rod **4** from the hole and place to the lock clip. Lower it to 20 cm above the closed position, then release it. It will latch automatically under its own weight.



The engine may be hot during operations in close proximity. In addition, the engine cooling fan may come on at any moment.
Risk of injury.



In the event of even a slight impact involving the radiator grille or bonnet, have the bonnet lock checked by an approved Dealer as soon as possible.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.
Risk of injury.

BONNET



Ensure that the bonnet is properly locked.
Ensure that nothing is preventing locking (grit, cloths, etc.).



Make sure nothing is left in the engine compartment (cloth, tools, etc.).
These may damage the engine or cause a fire.

ENGINE OIL LEVEL

Topping up, filling

It is normal for an engine to use oil for lubrication and cooling of moving parts and it is normal to top up the level between oil changes.

However, contact your approved Dealer if more than 0.5 litres is being consumed every 1,000 kms after the running in period.


5

Oil change frequency : check the oil level from time to time and certainly before any long journey to avoid the risk of damaging your engine.



In order to prevent splash-back, it is recommended that a funnel be used when topping up/filling with oil. Consult your approved dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.

Reading the oil level



- Remove the dipstick and wipe with a clean, lint-free cloth.
- Guide the dipstick in as far as it will go (for vehicles equipped with a cap-type dipstick, screw the cap in as far as it will go).
- Take out the dipstick again.
- Read the level : it should never fall below minimum mark or exceed maximum mark.

Once the operation has been completed, ensure that the dipstick is guided in as far as it will go or that the "cap-type dipstick" is completely screwed in.



Exceeding the maximum engine oil level


Under no circumstances must the maximum fill level be exceeded : risk of damage to the engine and catalytic converter.
If the oil level exceeds the maximum level, **do not start your vehicle** and contact an approved Dealer.




Before performing any action in the engine compartment, the ignition must be switched off by pressing the engine stop button (please see the information on "Starting, stopping the engine" in Section 2).

ENGINE OIL LEVEL

Topping up/Filling




The vehicle must be parked on level ground and the engine should be cold (for instance, before the engine is started up for the first time in the day).


 Do not exceed the **max** level and do not forget to refit cap **1**.


- Unscrew cap **1**.
- top up the level (as a guide, the capacity between the minimum and maximum reading on the dipstick **2**

is approximately 0.85 litres, (depending on the engine).
- wait for approximately 20 minutes to allow the oil to flow into the engine.
- check the level using the dipstick **2** (as described above).

Once the level has been read, ensure that the "cap-type dipstick" is completely screwed in.

 In order to prevent splash-back, it is recommended that a funnel be used when topping up/filling with oil.

 Consult an approved dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.

 Never run the engine in an enclosed space as exhaust gases are poisonous.



The engine may be hot during operations in close proximity. In addition, the engine cooling fan may come on at any moment.
Risk of injury.



Engine oil change : if you are changing the oil when the engine is hot, be careful not to scald yourself if the oil overflows.

Oil change

Service interval : refer to the Maintenance Document for your vehicle.

Oil change capacity

Please refer to the maintenance document for your vehicle, or contact an authorised dealer.

Always check the engine oil level using the dipstick, as explained previously (it should never fall below the minimum).

ENGINE OIL LEVEL

Engine oil grade

Refer to the maintenance document for your vehicle.

5



Exceeding the maximum engine oil level

The oil level should only be read with the dipstick as explained above. If the oil level exceeds the maximum level, **do not start your vehicle** and contact an approved dealer.




Filling and/or Checking the oil level:

Take care when topping up or checking the oil level. Make sure that no oil drips onto engine components. Remember to refit the cap securely, and put the dipstick back in place to avoid oil splashes onto hot engine components.

Fire hazard.

LEVELS, FILTERS

Brake fluid level



The level should be read with the engine switched off and on level ground.

This should be checked frequently, and immediately if you notice even the slightest loss in braking efficiency.

Level 7

It is normal for the level to drop as the brake shoes become worn, but it must never drop lower than the "MINI" warning line.

If you wish to check the disc and drum wear yourself, you should obtain the document explaining the

checking procedure from the network or the manufacturer's web site.

Topping up

After any operation on the hydraulic circuit, a specialist must replace the brake fluid.

Only use fluids approved by our Technical Department (and taken from a sealed container).

Replacement interval

Refer to the Maintenance Document for your vehicle.




If there is an abnormal or repeated drop in the fluid level, please consult an authorised dealer.



When working under the bonnet, the bonnet may be hot. The engine cooling fan may also start at any moment.

Risk of injury.

Coolant level



Check the level on flat ground, with the engine switched off. **When cold**, the level must be between the MINI and MAXI marks on the reservoir 2.

Top this level up when cold before it reaches the MINI mark.



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.

Frequency of checking coolant level

LEVELS, FILTERS

Check the coolant level regularly (very severe damage is likely to be caused to the engine if it runs out of coolant).

If the level needs to be topped up, only use products approved by our Technical Department which ensure

- antifreeze protection;
- an anti-corrosion protection of the cooling system.

Replacement intervals

Refer to the Maintenance Schedule for your vehicle.



Consult an approved dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.



No operations should be carried out on the cooling circuit when the engine is hot.

Risk of burns.




Before carrying out any action in the engine compartment, you must switch off the ignition.



For your safety, do not remove the bonnet holding straps.

Risk of the bonnet falling on the road surface.

Windscreen washer reservoir



Topping up

Engine switched off :

- open the cap **3** ;
- pull the extending funnel upwards as far as it will go ;
- fill until you can see the fluid ;
- push the funnel by pressing on it and replace the cap.

Liquid

Screen wash product (product with antifreeze in winter).

Filters

The filter elements (cabin filter etc.) should be replaced during the maintenance operations carried out on your vehicle.

Replacement intervals for filter elements : refer to the Maintenance Document for your vehicle.



When working under the bonnet, the bonnet may be hot. The engine cooling fan may also start at any moment.

Risk of injury.

LEVELS, FILTERS



When working in the engine compartment, ensure that the windscreen wiper stalk is in the park position.

Risk of injury.



For your safety, do not remove the bonnet holding straps.

Risk of the bonnet falling on the road surface.



Consult an approved dealer at once if you notice an abnormal or repeated drop in any of the fluid levels.




No operations should be carried out on the cooling circuit when the engine is hot.

Risk of burns.



Before carrying out any action in the engine compartment, you must switch off the ignition.

BATTERY



5

The battery **1** does not require any maintenance. **You must not open it or perform any added liquid.**

The charge status of your battery can decrease especially if you use your vehicle:

- for short journeys.
- for driving in town.
- when the temperature drops.
- after extended use of consumers (radio etc.) with the engine switched off.




Handle the battery with care as it contains sulphuric acid, which must not come into contact with eyes or skin. If it does, wash the affected area with plenty of water and see a doctor if necessary. Ensure that naked flames, red hot objects and sparks do not come into contact with the battery as there is a risk of explosion.



For your safety and the proper operation of the vehicle's electrical equipment (lights, windscreen wipers, braking assistance etc.), any work on the 12 V battery (removal, disconnection etc.) must be carried out by a specialist professional. Risk of serious burns or electric shocks. Respect categorically the replacement intervals (without exceeding them) as stated in the maintenance document. The battery is a specific type. Please ensure it is replaced with the same type. Contact an Authorised Dealer.

BATTERY



Label A

Observe the indications on the battery :

- **2** naked flames and smoking prohibited ;
- **3** eye protection required ;
- **4** keep away from children ;
- **5** explosive materials ;
- **6** please consult the vehicle user manual ;
- **7** corrosive materials.

Replacing the battery

As this operation is complex, we advise you to contact an approved Dealer.



The engine may be hot during operations in close proximity. In addition, the engine cooling fan may start at any moment.
Risk of injury.



Before carrying out any action in the engine compartment, you must switch off the ignition.



For your safety, do not remove the bonnet holding straps.
Risk of the bonnet falling on the road surface.

TYRE PRESSURE

Adhere to the tyre pressures (including the emergency spare wheel). The tyre pressures should be checked at least once a month and additionally before any long journey.

Tyre pressures should always be checked when the tyres are cold, ignore higher pressures which may be reached in hot weather or following a fast journey.

5

If the tyre pressures cannot be checked when the tyres are cold, increase the pressures from 0.2 to 0.3 bar (or 3 PSI).

Never deflate a hot tyre.

Refer the tyre pressure labels 1 details pasted on the driver door of the vehicle.



44163



For vehicles used fully laden (maximum permissible all-up weight)

The maximum speed must be limited to **(62 mph) 100 km/h** and the tyre pressure increased by 0.2 bar. Please refer to the information on "Weights" in Section 6.
Risk of tyre blowouts.



For your safety, please respect the speed limit. When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle. They must : either have a load capacity and speed rating at least equal to those of the original tyres, or conform to those recommended by an authorised dealer. Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness. Risk of loss of control of the vehicle.

BODYWORK MAINTENANCE

A well-maintained vehicle will last longer. It is therefore recommended to maintain the exterior of the vehicle regularly.

Your vehicle has been treated with very effective anti-corrosion products. It is nevertheless subject to various outside influences.

Corrosive agents in the atmosphere

- atmospheric pollution (in built-up and industrial areas);
- saline atmospheres (near the sea, particularly in hot weather);
- seasonal and damp climatic conditions (e.g. road salt in winter, water from road cleaners, etc.).

Minor impacts

Abrasive action

Dust and sand in the air, mud, road grit thrown up by other vehicles, etc.

You should take a number of minor precautions in order to safeguard your vehicle against such risks.

You should do the following

Wash your car frequently, **with the engine off**, with cleaning products recommended by our Technical Department (never use abrasive products). Rinse thoroughly beforehand using a jet washer:

- spots of tree resin and industrial pollution;
- mud in the wheel arches and underneath the body which forms damp patches;
- **bird droppings, which cause a chemical reaction with the paint that rapidly discolours paintwork and may even cause the paint to peel off;**

wash the vehicle **immediately** to remove these marks since it is impossible to remove them by polishing;

- salt, particularly in the wheel arches and underneath the body after driving in areas where the roads have been gritted.

Remove any plant matter (resin, leaves, etc.) from the vehicle regularly.

Respect local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

Observe the vehicle stopping distances when driving on gravelled surfaces to prevent paint damage.

Repair, or have repaired quickly, areas where the paint has been damaged, to prevent corrosion spreading.

Remember to visit the body shop periodically in order to maintain your

anti-corrosion warranty. Refer to the Maintenance Document.


Observe local regulations about washing vehicles (e.g. do not wash your vehicle on a public highway).

When washing the vehicle with a highpressure cleaning device, please take the following precautions:

- make sure that your vehicle's paintwork, the area or the component that you want to clean is compatible with this type of washing;
- the pressure delivered by the device must be less than 100 bar;
- when washing, position the spray nozzle at least 15 cm from the vehicle and check that the water flow rate is less than 15 l/min (3.30 gal);
- do not persist in washing the same area, impacted points or the seals (risk of damage to the paint, seals becoming detached, etc.).

If mechanical components, hinges, etc. have been cleaned, they must be protected again by spraying with products approved by our Technical Department.

BODYWORK MAINTENANCE

 We have selected special products to care for your vehicle and you can obtain these from the manufacturer's accessory outlets.

5

Do not do the following

Wash the vehicle in bright sunlight or freezing temperatures.

Do not scrape off mud or dirt without pre-wetting.

Allow dirt to accumulate on the exterior.

Allow rust to form following minor impacts.

Do not use solvents not approved by our Technical Department to remove stains as this could damage the paintwork.

Do not drive in snow or muddy conditions without washing the vehicle, particularly under the wheel arches and body.



Degrease or clean using high-pressure cleaning equipment or by

spraying on products not approved by our Technical Department :

- mechanical components (e.g. : engine compartment);
- underbody;
- parts with hinges (e.g. : inside the doors);
- painted plastic external fittings (e.g. : bumpers).

Doing this could give rise to corrosion or operational faults.

Vehicles with a matte paint finish

This type of paint requires certain precautions.

You should do the following

Wash the vehicle by hand using plenty of water, using a soft cloth or a gentle sponge.

Do not do the following

Use wax-based products (polishing). Rub too hard.

Wash the vehicle in a roller-type car wash. Attach stickers to the paintwork (risk of leaving marks).



Wash the vehicle using a high-pressure cleaning device.

Using a roller type car wash

Return the wiper stalk to the park position. Check the mounting of external accessories, additional lights and rear view mirrors, and ensure that the wiper blades are secured with adhesive tape.

Remove the radio aerial mast if your vehicle is fitted with this equipment.

Remember to remove the tape and refit the antenna after washing.

Cleaning the headlights, sensors and cameras

Use a soft cloth or cotton wool. If this does not clean them properly, moisten the cloth with soapy water, then wipe clean with a soft damp cloth or cotton wool.

Finally, carefully dry off with a soft dry cloth.

Do not use cleaning products containing alcohol or utensils (e.g. : a scraper).

INTERIOR TRIM MAINTENANCE

A well-maintained vehicle will last longer. It is therefore recommended to maintain the interior of the vehicle regularly.

A stain should always be dealt with swiftly.

Whatever type of stain is on the trim, use **cold (or warm) soapy water with natural soap**.

Detergents (washing-up liquid, powdered products, alcohol-based products) should not be used.

Use a soft cloth.

Rinse and soak up the excess.

instrument panel

(e.g. instrument panel, clock, radio display, etc.)

Use a soft cloth (or cotton wool).

Caution :

No liquid cleaning agents and water should be used to clean the Instrument panel.

It is recommended to use only soft and dry cloth to clean the instrument panel as there is no glass screen on the same.

Cleaning products containing alcohol must not be used under any circumstances.

Seat belts

These must be kept clean.

Use products selected by our Technical Department (Approved outlets) or warm, soapy water and a sponge and wipe with a dry cloth.

Detergents or dyes must not be used under any circumstances.

Textiles (seats, door trim, etc)

Vacuum-clean the textiles **regularly**.

Liquid stain

Use soapy water.

Dab lightly (never rub) with a soft cloth, rinse and remove the excess.

Solid or semi-solid stain

Carefully remove the excess solid or pasty material **immediately** with a spatula (working from the edges to the centre to avoid spreading the stain).

Clean in a similar way as a liquid stain.

Special instructions for sweets or chewing gum

Put an ice cube on the stain to solidify it, then proceed as for a solid stain.



For further recommendations for maintaining the interior, and/or for any unsatisfactory results, please see an authorised dealer.

Removal/replacing removable equipment originally fitted in the vehicle

If you need to remove equipment in order to clean the passenger compartment (for example, mats), always ensure that they are correctly refitted and they are at correct position. (The driver's mat should be fitted on the driver's side, etc.) and fit them with the components supplied with the equipment (for example, the driver mat should always be fixed using the pre-fitted mounting components).

With the vehicle stationary, ensure that nothing will impede driving (anything obstructing the pedals, heel wedged by the mat, etc.).

You should not :

You are strongly advised not to position objects such as deodorants, scents, etc. near air vents, as this could damage your dashboard trim.

INTERIOR TRIM MAINTENANCE



You are strongly recommended not to use high pressure or spray cleaning equipment inside the passenger compartment : use of such equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.

5



Use high-pressure cleaning equipment or sprays inside the passenger compartment :

Without careful use, this equipment could impair the correct functioning of the electrical or electronic components in the vehicle, or have other detrimental effects.




PUNCTURE, EMERGENCY SPARE WHEEL

In case of puncture


Depending on the vehicle, the following may be available:

- a tyre inflation kit;
- an emergency spare wheel.

Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel → 96.

Emergency spare wheel




The spare wheel is stored in cradle **3** underneath the floor at the rear of the vehicle.

To access the emergency spare wheel

- Have all passengers get out from the vehicle;
- Open the luggage compartment door and fold down the third row seat;
- loosen the bolt using the wheel-brace **1**;
- Unhook the cradle **3** by lifting upward direction to release it from the hook **4**;
- release the emergency spare wheel.



Do not loosen the bolt excessively, otherwise the spare wheel cradle may fall suddenly.



To store the wheel in the cage

- Make sure to reposition the wheel **2** correctly in the cradle, with the valve facing downwards;
- place the wheel as far to the right as possible and at the bottom of the cradle **3** (movement **A**);
- lift the cradle **3** towards upward direction and re-fit into hook **4**;
- tighten the nut using the wheel-brace **1** to refit and lock the assembly;
- fold the third row seat back to the desired position.

PUNCTURE, EMERGENCY SPARE WHEEL



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.



Do not leave the tools unsecured inside the vehicle as they may be projected during braking. After use, make sure the tools are correctly positioned in their mountings: **failure to do so presents a risk of injury**. If bolts are supplied with the emergency spare wheel, you must use these bolts only for the emergency spare wheel.



If the emergency spare wheel has been stored for several years, have it checked by your

Dealer to ensure that it is safe to use.

Vehicle fitted with an emergency spare wheel that differs from the other wheels :

- Never fit more than one emergency spare wheel to the same vehicle.
- The punctured wheel is wider than the emergency spare wheel, so the height of the vehicle ground clearance is reduced.
- Replace the emergency spare wheel as soon as possible with a wheel identical to the original one.
- When this is fitted to the vehicle, which must only be a temporary measure, the driving speed must not exceed the speed indicated on the label on the wheel.
- Fitting an emergency spare wheel may alter the way the vehicle usually runs.

Avoid sudden acceleration or deceleration and reduce your speed when cornering.




Note: Ensure that the emergency spare wheel or punctured wheel are correctly positioned. Check that the boot carpet is correctly positioned in its bump stops to prevent it from being damaged.



Note: Do not fit the wheel cover if the emergency spare wheel is fitted to the vehicle.


WHEEL TRIM, TOOLS

Central wheel trim with visible wheel bolts




Depending on the version, the bolts are directly accessible or after removing the wheel cap **1**.

Accessing the tools



Depending on the vehicle, to access the tools:

- move the second row right side seat **1** in forward direction → **125**;
- release the knob **6** and swing out the lever **7** to access the tools.



Jack **2**

To use jack **2**, move the second row right side seat forward → **125** and re-

WHEEL TRIM, TOOLS

lease knob **6**. Swing out the lever **7** and take out the jack **2**. To store the jack after use, ensure the jack is located in the same position, swing out the lever **7** again and tighten the knob **6**.

Wheel wrench **3**

This can be used to lock or unlock the wheel bolts and the towing eye **5**.

This is placed along with warning triangle. Replace it in the same pouch after use.

Guide wheel bolt **4**

Towing eye **5** → 177

6



Do not leave the tools unsecured inside the vehicle as they may be projected during braking. After use, check that all the tools are correctly clipped into the tool kit, then position it correctly in its housing to reduce any risk of injury.

If bolts are supplied with the emergency spare wheel, you must use these bolts only for the emergency spare wheel.



For safety reasons, the use of a jack not recommended by the manufacturer is strictly

forbidden.

The jack is specific to the vehicle and used to change the wheels.


Under no circumstances should it be used:

- on another vehicle;
- to carry out a repair;
- to access the underside of the vehicle.

Risk of injury.

Risk of damage to the vehicle.

CHANGING A WHEEL



Switch on the hazard warning lights. Keep the vehicle away from traffic and on a level surface where it will not slip.

Apply the parking brake and engage a gear (first or reverse, or **P** for automatic transmissions). Ask the passengers to leave the vehicle and to keep away from traffic.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.

Start cranking the jack by hand, positioning the jack support plate **4** in the slightly indented groove underneath the vehicle, located between the two notches **5** and in the direction of the arrow **3**.

Continue to crank the jack so that the baseplate is correctly positioned

Vehicles equipped with a jack and wheel wrench

If necessary, remove the wheel trim.

Unlock the wheel bolts using the wheel wrench **1**.

Position it so as to be able to push from above.

Position the jack **2** horizontally.

The jack head **must** be lined up with the sill closest to the wheel affected and indicated by the arrow **3**.

(it should be underneath the vehicle and aligned with the jack head).

Turn it a few times to lift the wheel off the ground.

Undo the bolts and take off the wheel.

Fit the emergency spare wheel on the central hub and turn it to locate the mounting holes in the wheel and the hub.

Tighten the bolts, checking that the wheel is correctly positioned on its hub.

Lower the jack.

With the wheel on the ground, tighten the bolts fully and have the tightness of the bolts checked and the emergency spare wheel pressure checked as soon as possible.



If you have a puncture, replace the wheel as soon as possible.

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist.

CHANGING A WHEEL



Do not leave the tools unsecured inside the vehicle as they may be projected during braking. After use, check that all the tools are correctly clipped into the tool kit, then position it correctly in its housing to reduce any risk of injury.

If bolts are supplied with the emergency spare wheel, you must use these bolts only for the emergency spare wheel.



For safety reasons, the use of a jack not recommended by the manufacturer is strictly forbidden.

The jack is specific to the vehicle and used to change the wheels.

Under no circumstances should it be used:

- on another vehicle;
- to carry out a repair;
- to access the underside of the vehicle.

Risk of injury.

Risk of damage to the vehicle.

TYRES

The tyres are the only contact between the vehicle and the road, so it is essential to keep them in good condition.

You must make sure that your tyres conform to local road traffic regulations.



For your safety, please respect the speed limit. When they need to be replaced, only tyres of the same make, size, type and profile should be used on a single axle.

They must : either have a load capacity and a speed capacity at least equal to the original tyres, or correspond to those recommended by your authorised dealer.

Failure to heed these instructions could endanger your safety and affect your vehicle's roadworthiness.

Risk of loss of control of the vehicle.

Maintaining the tyres



The tyres must be in good condition and the tread form must have sufficient depth ; tyres approved by our Technical Department have tread wear indicators **1** which are **indicators moulded into the tread at several points.**

When the tread has worn down to the wear warning strips, **these strips will become visible 2 : it is then necessary to replace your tyres because the tread rubber is now only 1.6 mm deep at most, resulting in poor road holding on wet roads.**

An overloaded vehicle, long journeys by motorway, particularly in very hot weather, or continual driving on

poorly surfaced minor roads will lead to more rapid tyre wear and affect safety.



Incidents which occur when driving, such as striking the kerb, may damage the tyres and wheel rims, and could also lead to misalignment of the front or rear axle geometry. In this case, have the condition of these checked by an approved dealer.

Tyre pressures

Adhere to the tyre pressures (including the emergency spare wheel). The tyre pressures should be checked at least once a month and additionally before any long journey (refer to the label affixed to the edge of the driver's door).

TYRES



Incorrect tyre pressures lead to abnormal tyre wear and unusually hot running. These are factors which may seriously affect safety and lead to :

- poor road holding.
- risk of bursting or tread separation.

The pressure depends on the load and the speed of use. Adjust the pressure according to the conditions of use (refer to the label affixed to the edge of the driver's door).

The pressures should be checked cold : ignore higher pressures which may be reached in hot weather or following a high speed journey.

If the tyre pressures cannot be checked when the tyres are **cold, increase the pressures from 0.2 to 0.3 bar (or 3 PSI).**

Never deflate a hot tyre.


Special note

Depending on the vehicle, there may be an adapter which needs to be positioned on the valve before air is added.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and lead to pressure loss. Always use valve caps identical to those fitted originally and tighten them fully.

Changing wheels around



44175

Swap the wheels as shown in above picture with every regular intervals 12 months / 10000 Kms (which ever comes earlier).

Swapping needs to be done along with wheel balancing and wheel alignment.

Emergency spare wheel

Refer to the information on the "Emergency spare wheel" and "Changing a wheel" in Section 5.



Fitting new tyres

For safety reasons, this operation must be carried out by a specialist.

Fitting different tyres may change your vehicle as follows :

- it may mean that your vehicle no longer conforms to current regulations.
- it may change the way it handles when cornering.
- it may cause the steering to be heavy.
- It may affect the use of snow chains.

TYRES



Changing a wheel

As the tyre pressure monitor may take several minutes to correctly determine the positions of the wheels and the pressure values after driving, check the tyre pressures following any operation.

Use in winter

Chains

For safety reasons, fitting snow chains to the rear axle is strictly forbidden.

Chains cannot be fitted to tyres which are larger than those originally fitted to the vehicle.

Snow or Winter tyres

We would recommend that these be fitted to all **four wheels** to ensure that your vehicle retains maximum adhesion.

Warning : These tyres sometimes have a specific direction of rotation and a maximum speed index which may be lower than the maximum speed of your vehicle.



Snow chains may only be fitted to tyres of the same size as those originally fitted to **your vehicle**.

Studded tyres

This type of equipment may only be used for a limited period and as laid down by local legislation. It is necessary to observe the speed specified by current legislation.

These tyres must, at a minimum, be fitted to the two front wheels.

Snow or Winter tyres

We recommend that these be fitted to all four wheelers to ensure that your vehicle remains maximum adhesion.

Warning :

These tyres sometimes have a specific direction of rotation and a maximum speed index which may be lower than the maximum speed of your vehicle.



In all cases, we would recommend that you contact an authorised dealer who will be able to advise you on the choice of equipment which is most suitable for your vehicle.

Tyre inflation kit



TYRES



The kit repairs tyres when the tread **A** has been damaged by objects smaller than 6 mm. It cannot repair all types of puncture, such as cuts larger than 6 mm, cuts in the tyre sidewall **B**, etc. Ensure also that the wheel rim is in good condition. Do not pull out the foreign body causing the puncture if it is still in the tyre.



Do not attempt to use the inflation kit if the tyre has been damaged as a result of driving with a puncture. You should therefore carefully check the condition of the tyre sidewalls before any operation. Driving with underinflated, flat or punctured tyres can be dangerous and may make the tyre impossible to repair.

This repair is temporary.

A tyre which has been punctured should always be inspected (and repaired, where possible) by a specialist as soon as possible. When taking a tyre which has been repaired using this kit to be replaced, you must inform the specialist. When driving, vibration may be felt due to the presence of the repair product injected into the tyre.



The kit is only approved for inflating the tyres of the vehicle originally equipped with the kit. It must never be used to inflate the tyres of another vehicle, or any other inflatable object (rubber ring, rubber boat, etc.). Avoid spillage on skin when handling the repair product bottle. If droplets do leak out, rinse them off with plenty of water. Keep the repair kit away from children. Do not dispose of the empty bottle in the countryside. Return it to your approved dealer or to a recycling organisation. The bottle has a limited service life which is indicated on its label. Check the expiry date. Contact an approved dealer to replace the inflation tube and repair product bottle.

TYRES



Depending on the vehicle, the tyre inflation kit **C** is located in the boot.




Before using the kit, park the vehicle at a sufficient distance from traffic, switch on the hazard warning lights, apply the parking brake, ask all passengers to leave the vehicle and keep them away from traffic.



If the vehicle is parked on the hard shoulder, you must warn other road users of your vehicle's presence with a warning triangle or with other devices as per the legislation applying to the country you are in.




Vehicle fitted with a tyre pressure monitoring system

In the event of under-inflation (punctures, under-inflation etc.), the  warning light appears on the instrument panel → 96.

In the event of a puncture

62281



With the engine running and the parking brake applied:

- disconnect any accessories that are connected to the vehicle's accessories sockets;
- for vehicles fitted with a towing device, disconnect the towbar socket if needed;
- **refer to the information on the inflation kit compressor** located in the vehicle luggage compartment and follow the instructions for use;
- inflate the tyre to the recommended pressure → 142;
- after a maximum of 15 minutes, stop inflating and read the pressure (on the pressure gauge 2).

TYRES

Note: while the container is emptying (approximately 30 seconds), the pressure gauge 2 will briefly indicate a pressure up to 6 bar, then the pressure drops;

- adjust the pressure: to increase it, continue inflation with the kit. To reduce it, press the button 7.

If the recommended pressure of 1.8 bar cannot be achieved after 15 minutes, repair is impossible. Do not drive the vehicle. Consult an approved dealer.

Once the tyre is correctly inflated, remove the kit: slowly unplug the inflation adapter from the container to prevent any product spatter, then store the container in plastic packaging to prevent the product from leaking.

- Affix the driving recommendation label (located under the container) to the dashboard where the driver can see it.

- Put the kit away.

- At the end of this initial inflation operation, air will still escape from the tyre. You must drive a short distance in order to seal the hole.

- Start immediately and drive at a speed between 20 to 60 km/h (12 to 37 mph) in order to distribute the product evenly in the tyre. After dri-

ving a distance of 3 km (2 miles), stop and check the pressure.

- If the pressure is higher than 1.3 bar but lower than the recommended pressure (refer to the label affixed to the edge of the driver's door), adjust it. Otherwise, contact an approved dealer: the tyre cannot be repaired.

Precautions when using the kit

The kit should not be operated for more than 15 consecutive minutes.



Nothing should be placed around the driver's feet as during sudden braking such objects may slide under the pedals and obstruct their use.

The container must be replaced after the first use even if liquid remains inside.



Please be aware that a poorly tightened or missing valve cap can make the tyres less airtight and may lead to pressure loss. Always use valve caps identical to the originals and screw them down fully.



Following repair with the kit, do not travel further than 200 km (124 miles). In addition, reduce your speed and under no circumstances exceed 80 km/h (50 mph). The sticker, which you must affix in a prominent position on the dashboard, reminds you of this. Depending on the country or local legislation, a tyre repaired with the inflation kit will need to be replaced.

HEADLIGHTS, LIGHTS: CHANGING BULBS

Exterior lighting: changing bulbs


Front headlights: changing the bulbs




The engine may be hot during operations in close proximity. In addition, the engine cooling fan may come on at any moment.

Risk of injury.

Dipped beam headlight 1




Remove the cover **A**.



Unclip the connector **5**, remove the assembly from its housing and take out the bulb.

Bulb type: H7.

Main beam hexadlight 2



Remove the cover **B**.

Unclip the connector **6**, remove the assembly from its housing and take out the bulb.

Bulb type: H1.

Before replacing the bulb, make a careful note of its position in its housing. After changing it, check that the replacement bulb is in exactly the same position in the housing. Clip the cover in place.

Side light 3

HEADLIGHTS, LIGHTS: CHANGING BULBS

Unclip the connector **7**, remove the assembly from its housing and take out the bulb.

Bulb type: W5W.

Direction indicator lights 4

turn the bulb holder **8** a quarter of a turn and take out the bulb.

Bulb type: PY21W.

LED daytime running light 5

(depending on the vehicle)

Consult an approved dealer.

6



The bulbs are under pressure and can break when replaced.

Risk of injury.



Before carrying out any action in the engine compartment, you must switch off the ignition → **77**.



Any operation on (or modification to) the electrical system must be performed by an approved Dealer since an incorrect connection might damage the electrical equipment (harness, components and in particular the alternator). In addition, your Dealer has all the parts required for fitting these units.



The headlamps can be replaced. However, we recommend you to have them replaced with an approved dealer, if it proves difficult. To comply with legislation, or as a precaution, you can obtain an emergency kit containing a set of spare bulbs and fuses from an approved dealer.

Rear lights: changing bulbs

Side/ Brake lights and direction indicator lights

67363



Open the luggage compartment lid and remove the screws **1**.

Release the lamp assembly by pulling the lamp outwards.

HEADLIGHTS, LIGHTS: CHANGING BULBS



Rotate bulb holders **2** & **3** in anti-clockwise direction and remove the bulbs.

Side light/brake lights 2

Bulb type: P21/5W


Direction Indicator lights 3

Bulb type: PY21W




Do not touch the exhaust.
Risk of burns.

Reversing light



open the luggage compartment lid.
remove the panel **4** by removing the screws **5**.



unscrew the nut **6** and clips to release the light assembly from the outside of the vehicle by pulling towards the outside.



Unclip the connector and rotate the bulb holder **7** in anti-clockwise direction to remove the bulb concerned.

Bulb type: W16W



The bulbs are under pressure and can break when replaced.
Risk of injury.

Refitting

6

HEADLIGHTS, LIGHTS: CHANGING BULBS

To re-fit, proceed in the reverse order taking care not to damage the wiring, tighten screws **7** first.

LED high-level brake light **8**



67348


6

Consult an approved dealer.




The bulbs are under pressure and can break when replaced.
Risk of injury.

Number plate lights **9**



67349

Unclip the light **9** by pressing the tab **10** using a flat-blade screwdriver or similar tool.



67350

Remove the bulb **11** from the holder.

Bulb type: W5W.

Refitting

To refit, proceed in the reverse order, taking care not to damage the wiring. Once the bulb has been replaced, check that it is properly secured.


LED Side indicator lights **12**



67706

Consult an approved dealer.

HEADLIGHTS, LIGHTS: CHANGING BULBS



Side indicator lights 13


(depending on the vehicle)

Unclip the indicator light **13** using a flat-blade screwdriver or similar tool positioned at **14** to lever the indicator light towards the outside of the vehicle.




The bulbs are under pressure and can break when replaced.

Risk of injury.



Make a quarter of a turn (movement **15**) on the bulb holder **16** and remove the bulb **17** (movement **18**).




Bulb type: WY5W.

Replace the bulb and refit the indicator light.

Interior lighting: changing bulbs


Front courtesy light 1



Unclip the light **1** using a tool such as a flat-head screwdriver positioned at **A**.

HEADLIGHTS, LIGHTS: CHANGING BULBS

6




- Remove the bulb from the holder **2**.

Bulb type: Festoon tube 12V.

Refitting

- clip in the courtesy light **1** until you hear the click;
- ensure that the interior lights are properly positioned and locked into place.

Rear reading light 3



- Unclip the light **3** using a tool such as a flat-head screwdriver positioned at **B**.



- Remove the bulb from the holder **4**.

Bulb type: Festoon tube 12V.


Refitting

- clip in the courtesy light **3** until you hear the click;
- ensure that the interior lights are properly positioned and locked into place.



The bulbs are under pressure and may break when replaced.
Risk of injury.

FUSES



Passenger compartment fuses **A**

If any electrical component does not work, check the condition of the fuses.

Pull the flap **A** from the lower edge to remove it to access the fuses.



To comply with current legislation, or as a precaution, you can obtain an emergency kit from your approved dealer containing a set of spare bulbs and fuses.

Removing the fuses

Remove the fuse, located at the back of flap **A** from position.

To remove the fuse, slide the fuse.

It is not advisable to use the free fuse locations.



The engine may be hot when working in close proximity. In addition, the engine cooling fan may come on at any moment.

Risk of injury.




Check the fuse in question and replace it, If a fuse is fitted where the rating is too high, it may cause the electrical circuit to overheat (risk of fire) in the event of an item of equipment using an excessive amount of current.

FUSES

Allocation of fuses in the passenger compartment

(presence of some fuses DEPENDS ON VEHICLE EQUIPMENT LEVEL)



44144

FUSES

| Number | Allocation |
|----------|---|
| A | Defroster/Front power window |
| B | Reverse lights/Front blower (Manual transmission) |
| C | Day light Running lamps |
| D | Anti-pinch |
| E | Hands free access ECU |
| F | Rear AC/2nd & 3rd row Accessory socket |
| G | Front blower (Automatic transmission) |
| H | Power window - Front/Rear |
| I | Child safety |

| Number | Allocation |
|----------|--|
| 1 | Rear AC |
| 2 | Parking assistance/ Outside Rear View Mirror (AU-TO) |
| 3 | Multimedia CAN interface |
| 4 | Not used |

| | |
|---------------|--|
| 5 | Child safety |
| 6 | Rear power window |
| 7 | BCM/Radio/Ultra low cost navigation |
| 8 | Hands-free mode |
| 9 | Hands-free mode |
| 10 | Not used |
| 11 | Starter - Non Hands-free mode |
| 12 | Roof light - Front/Rear |
| 13 | Cluster |
| 14 | Combi switch |
| 15 | Radio/Ultra low cost navigation |
| 16 | Combi switch - low beam |
| 17 | Body control module |
| 18 | Horn |
| 19 | Door locking/Tail gate |
| 20 | Body control module |
| 21, 22 | Not used |
| 23 | Electric Outside Rear View Mirror adjustment |
| 24 | Not used |

| | |
|---------------|--|
| 25 | Defroster |
| 26 | Backup light/Rear wiper |
| 27 | Wiper motor |
| 28 | BCM/Fuel pump relay/ starter relay/Injection ECU/Power transmission control unit/Automatic gear selector |
| 29 | Electric power steering |
| 30 | Air bag |
| 31 | Stop light/Ultra low cost navigation |
| 32 | Transponder/ABS/clutch travel end/stop light |
| 33 | Second row accessory socket |
| 34 | Third row accessory socket |
| 35, 36 | Not used |
| 37 | Front blower motor |
| 38 | Outside rear view mirror |
| 39 | Not used |
| 40 | Left hand side head light - High beam |

FUSES

| | |
|--------------|--|
| 41 | Right hand side head light - High beam |
| 42 | Left hand side head light - Low beam |
| 43 | Right hand side head light - Low beam |
| 44 | Position lamp |
| 45 | First row accessory socket |
| 46 | Front power window - Normal/Anti-pinch |
| 47 | Power window Anti-pinch |
| 48,49 | Not used |

BATTERY

Troubleshooting

To avoid all risk of sparks :

- Ensure that all electrical equipments (courtesy lights, etc.) are switched off before disconnecting or reconnecting the battery.
- when charging, stop the charger before connecting or disconnecting the battery.
- to avoid creating a short circuit between the terminals, do not place metal objects on the battery.
- always wait at least one minute after the engine has been switched off before disconnecting a battery.
- make sure that you reconnect the battery terminals after refitting.

Connecting a battery charger

The battery charger must be compatible with a battery with nominal voltage of 12 volts.

Do not disconnect the battery when the engine is running. **Follow the instructions given by the manufacturer of the battery charger you are using.**



Some batteries may have specific conditions for recharging. Consult your approved dealer. Avoid the risk of sparks, as this could cause a sudden explosion, and always charge the battery in a well-ventilated area.
Risk of serious injury.



Handle the battery with care as it contains sulphuric acid, which must not come into contact with eyes or skin. If it does, wash the affected area with plenty of cold water and consult a doctor, if necessary. Ensure that naked flames, red hot objects and sparks do not come into contact with the battery as there is a risk of explosion.
The engine may be hot when carrying out operations in close proximity. In addition, the engine cooling fan can come on at any moment.
Risk of injury.

Starting the vehicle using the battery from another vehicle

If you have to use the battery from another vehicle to start, obtain suitable jump leads (with a large cross section) from an approved dealer or, if you already have jump leads, ensure that they are in perfect condition.

BATTERY


The two batteries must have an identical nominal voltage of 12 volts.

The battery supplying the current should have a capacity (amp-hours, Ah) which is at least the same as that of the discharged battery.

Ensure that there is no risk of contact between the two vehicles (risk of short circuiting when the positive terminals are connected) and that the discharged battery is properly connected. Switch off your vehicle ignition.

Start the engine of the vehicle supplying the current and run it at an intermediate engine speed.

47827



Connect the positive cable (+) **A** to the (+) terminal **1** of the discharged

battery, then to the (+) terminal **2** of the battery supplying the current.

Connect the negative cable (-) **B** to the (-) **3** terminal of the battery supplying the current and then to the (-) **4** terminal of the discharged battery.

Start the engine as normal. As soon as it starts, disconnect cables **A** and **B** in reverse order (**4-3-2-1**).



Check that there is no contact between leads **A** and **B** and that the positive lead **A** is not touching any metal parts on the vehicle supplying the current. Risk of serious injury and/or damage to the vehicle.

RADIO FREQUENCY REMOTE CONTROL

Batteries

Operating faults

If the battery is too weak to ensure correct operation, you can still start and lock/unlock the vehicle → 30



When replacing :
- make sure that the batteries are correctly inserted.

Risk of explosion.

- if the flap does not close correctly, do not use and keep out of reach of children.

44159




Replacing the battery

Open the case at slot **1** using a flat-blade screwdriver or similar, and replace the battery **2**, observing the type and polarity shown on the back of the cover.

Ensure that the cover is correctly clipped on and the screw tightened.

Note : It is not advisable to touch the electronic circuit in the key cover when replacing the battery.

44160



When they need to be replaced, be sure to use the same or equivalent type of battery (consult an approved Dealer).

RADIO FREQUENCY REMOTE CONTROL



Precautions relating to batteries :

- keep (new or used) batteries out of reach of children ;
 - do not swallow batteries ;
- Risk of chemical burns which may prove fatal.
- if ingested or inserted into any part of the body, consult a doctor as soon as possible.



Do not throw away your used batteries ; give them to an organisation responsible for collecting and recycling batteries.



The batteries are available from approved dealers, and their service life approximately two years. Check that there is no dye on the battery : risk of an incorrect electrical contact.

6

44162



HANDS FREE CARD

Replacing the battery



When the message "Keycard Battery Low" appears on the instrument panel, replace the battery in the card:

- slide the rear casing **1** downwards while pressing on zone **A** ;
- remove the battery cover **2** ;
- remove the battery by pressing on one side and lifting the other ;
- replace it according to the direction and template shown inside the cover.



When refitting, proceed in the reverse order, then press one of the buttons on the card four times, close to the vehicle : the message will disappear.

Check that the cover is clipped shut.

Note : Do not touch the electronic circuit or contacts on the card when replacing the battery.



Operating faults

If the battery is too weak to ensure correct operation, you can still start and lock/unlock the vehicle (please refer to the information on "Locking/unlocking the opening elements" in Section 1).

HANDS FREE CARD



When replacing :

- make sure that the batteries are correctly inserted.

Risk of explosion.

- if the flap does not close correctly, do not use and keep out of reach of children.



Precautions relating to batteries :

- keep (new or used) batteries out of reach of children ;

- do not swallow batteries ;

Risk of chemical burns which may prove fatal.

- if ingested or inserted into any part of the body, consult a doctor as soon as possible.

6



Do not throw away your used batteries ; give them to an organisation responsible for collecting and recycling batteries.




The batteries are available from approved dealers, and their service life approximately two years. Check that there is no dye on the battery : risk of an incorrect electrical contact.




When they need to be replaced, be sure to use the same or equivalent type of battery (consult an Approved Dealer).

WINDSCREEN WIPER - TO LIFT/REPLACE WIPER BLADES



Replacing windscreen wiper blades 1

- With the ignition off, lift wiper arm **3**.
- Turn the blade horizontally (movement **A**).
- Press tab **2** and slide the wiper blade downwards (movement **D**) until hook **4** on the wiper arm is released.
- Slide the blade (movement **C**) then lift it (movement **B**) to release it.



Replacing the rear screen wiper blades 5

- With the ignition off, lift wiper arm **6**.
- Turn blade **5** until some resistance is met (movement **E**).
- Pull the blade to release it (movement **F**).

Refitting windscreen wiper blades

To refit the wiper blade, proceed in the reverse order to removal. Make sure that the blade is correctly locked in position.

i Check the condition of the wiper blades. You are responsible for their service life:

- clean the blades, windscreen and rear screen regularly with soapy water;
- do not use them when the windscreen or rear screen are dry;
- free them from the windscreen or rear screen when they have not been used for a long time.

WINDSCREEN WIPER - TO LIFT/REPLACE WIPER BLADES



- In frosty weather, make sure that the wiper blades are not stuck by ice (to avoid the risk of the motor overheating).
- Check the condition of the wiper blades.

Replace the wiper blades as soon as they begin to lose efficiency (approximately once a year).

While changing the blade, take care not to drop the arm onto the window after it has been removed as this may break the window.

6



TOWING




The steering wheel must be unlocked and the ignition key must be in ignition ON condition to provide brake lights and hazard warning lights on the towed vehicle. At night the vehicle must have its lights on.


Front towing point.


Remove the tow hook cover **1** to access the tow hook. This towing point must only be used for towing: never use it for lifting the vehicle directly or indirectly.

Before towing, unlock the steering column. Press clutch and shift the gear lever to 1st gear (**N/R in automatic transmission vehicle**). **Insert the hands free card into the card reader, press and hold the engine**

start button for 2 seconds. Shift the gear lever to N (position N in automatic transmission vehicle). The steering column gets unlocked and accessory mode gets ON to have the brake lights and hazard warning lights ON in the towed vehicle.

 Ensure the towing hook should be fitted completely until the end of thread.

 Always pull straight ahead when using tow hooks. It is prohibited to pull the vehicle from sides or at a vertical angle.

 Do not remove the hands-free card from the drive while towing.



Do not remove the key from the ignition when the vehicle is being towed.

When the engine is stopped, steering and braking assistance are not operational.

- Do not leave the tools unsecured inside the vehicle as they may come loose under braking;
- A vehicle must not be towed if it is not fit to be driven;
- Use a rigid towing bar. If a rope or cable is used (where the law allows this), the vehicle being towed must be able to brake.



Do not leave the tools unsecured inside the vehicle as they may come loose under braking.

ing.

TOWING



It is prohibited to hang the car to lower arm or Rear Axle. To hang car there is a specific place provided.



INSTALLATION AND USE OF ACCESSORIES



Electrical and electronic accessories

Before installing this type of accessory (particularly for transmitters/receivers: frequency bandwidth, power level, position of the aerial, etc.), make sure it is compatible with your vehicle. Contact an approved dealer.

Before connecting an accessory to a socket, ensure that it does not exceed the maximum power authorised for the socket → 130, → 124.

Fire hazard.

No work may be carried out on the vehicle's electrical and/or electronic circuits, except by a qualified professional. In fact, an incorrect connection and/or the installation of electrical/electronic accessories not approved by the manufacturer could lead to:

- damage to the electrical and/or electronic equipment;
- damage to the components connected to it;
- the collection and use of vehicle data;
- an invasion of privacy (modification, deletion or unwarranted access to personal data);
- cancellation of the authorisation for entry into service.

Risk of serious accidents.

Risk of invasion of privacy.

If you have electrical equipment fitted in future, make sure that you obtain information on the rating and position of this fuse.

Using the diagnostic socket

The use of electronic accessories on the diagnostic socket may cause serious disturbance to the vehicle's electronic systems. For your safety, we recommend that you only use electronic accessories approved by the manufacturer: consult an approved dealer.

Risk of serious accidents

Fitting aftermarket accessories

If you wish to install accessories on the vehicle: consult an approved dealer. Also, to ensure the correct operation of your vehicle, and to avoid any risk to your safety, we recommend that you use only accessories specifically designed for your vehicle, which are the only accessories for which the manufacturer will provide a warranty.

If you are using an anti-theft device, only attach it to the brake pedal.

INSTALLATION AND USE OF ACCESSORIES

Driver obstruction

On the driver's side, only use mats suitable for the vehicle, attached with the pre-fitted components, and check the fitting regularly. Do not lay one mat on top of another.

There is a risk of wedging the pedals.

OPERATING FAULTS

The following advice will enable you to carry out quick, temporary repairs. For safety reasons you should always contact an approved dealer as soon as possible.

| The starter is activated | POSSIBLE CAUSES | WHAT TO DO |
|---|---|---|
| Warning lights dim or fail to come on ; the starter does not run. | Battery terminals disconnected, oxidised or incorrectly secured. | Retighten them, reconnect them or clean them if they are oxidised. |
| | Battery discharged or worn. | Connect another battery to the faulty battery. Refer to the information on "Battery : troubleshooting" in Section 5 or replace the battery if necessary. Do not push the vehicle if the steering column is locked. |
| The engine is not starting. | Starting conditions are not fulfilled. | Please refer to the information on "Starting, stopping the engine" in Section 2. |
| The steering column remains locked. | Steering wheel locked. | To unlock, gently move the key and the steering wheel (refer to the information on the "Ignition switch" in Section 2). |
| Traces of condensation in the lights. | This is not a fault. Traces of condensation are a natural phenomenon caused by variations in temperature. The traces will disappear slowly once the lights are switched on. | |
| On the road | POSSIBLE CAUSES | WHAT TO DO |
| Vibrations. | Tyres not inflated to correct pressures, incorrectly balanced or damaged. | Check the tyre pressures ; if this is not the cause, have their condition checked by an approved dealer. |
| Coolant boiling in the coolant reservoir. | Mechanical fault : cylinder head gasket damaged, faulty coolant pump. | Stop the engine. Contact an approved dealer. |

OPERATING FAULTS

| On the road | POSSIBLE CAUSES | WHAT TO DO |
|--|---|--|
| | Engine cooling fan not working. | Contact an approved dealer. |
| Smoke under the bonnet. | Short circuit or cooling system leak. | Stop, switch off the ignition, move away from the vehicle and contact an approved dealer. |
| The oil pressure warning light comes on : on a bend or under braking at idle speed | The engine oil level is too low. Low oil pressure. | Top up the engine oil level (refer to the information on "Engine oil level : topping up/filling" in Section 4). Go to your nearest approved dealer. |
| The oil pressure warning light takes a long time to go out or remains lit during acceleration. | Loss of oil pressure. | Stop the vehicle : contact an approved dealer. |

6

| On the road | POSSIBLE CAUSES | WHAT TO DO |
|---|---------------------------------|--|
| The engine overheats. The coolant temperature indicator light comes on. | Engine cooling fan not working. | Stop the vehicle, switch off the engine and contact an approved dealer. |
| | Coolant leaks. | Stop the vehicle, switch off the engine and check the coolant reservoir : it should contain fluid. If there is no coolant, consult an approved dealer as soon as possible. |
| The wiper does not work. | Wiper blade stuck. | Free the blades before using the wipers. |
| | Faulty electrical circuit. | Consult an approved dealer. |
| The wiper does not stop. | Faulty electrical controls. | Consult an approved dealer. |


OPERATING FAULTS

| On the road | POSSIBLE CAUSES | WHAT TO DO |
|---|---|---|
| Direction indicators flashing more quickly. | Bulb blown. | Replace the bulb. |
| The direction indicators do not work. | Faulty electrical circuit. | Consult an approved dealer. |
| The headlights do not switch on or off. | Faulty electrical circuit or control. | Consult an approved dealer. |
| Abnormal white smoke from the exhaust | Mechanical fault: damaged cylinder head gasket. | Stop the engine. Contact an approved dealer. |



Radiator : If there is a significant lack of coolant, remember that it must never be topped up using cold coolant while the engine is very warm. After any procedure on the vehicle which has involved even partial draining of the cooling system, it must be refilled with a new mixture prepared in the correct proportions. Reminder : only products approved by the Technical Department may be used for this purpose.

VEHICLE IDENTIFICATION PLATES



7

The information shown on the vehicle identification plate should be quoted on all correspondence or orders.


Open up the bonnet to access the Vehicle Identification number Plate.

Vehicle identification plate A

Identification number.



ENGINE IDENTIFICATION PLATES




Please quote the information on the engine plate or label **B** in all correspondence or orders.

(Location varies depending on engine)

1. Engine type.
2. Engine suffix.
3. Engine number.

Engine identification plate **B**

Identification number



ENGINE SPECIFICATIONS



| | |
|--|--|
| Versions | 1.0 12V |
| Engine type (see engine plate) | BR10DE / B4D |
| Cubic capacity (cc) | 999 |
| Type of fuel octane rating | Petrol. It is essential to use unleaded petrol with an octane rating 91 and higher. |
| Spark plugs | Only use spark plugs specified for your vehicle's engine. The type should be marked on a label stuck inside the engine compartment.If it is not, then Contact your approved Dealer for replacement of Spark Plugs. Fitting spark plugs which are not to specification may damage the engine. |

ENGINE SPECIFICATIONS


| | |
|---|--|
| Versions | 1.0 12V |
| Engine type (see engine plate) | BR10DE / B4D |
| Cubic capacity (cc) | 999 |
| Fuel types that meet Indian standards and are compatible with the engines of vehicles sold in India (in any other case, contact an Approved Dealer). | <p>E10 Unleaded petrol compliant with standard IS 2796: 2017 containing up to 10% ethanol in volume.</p> <p>E20 Unleaded petrol compliant with standard IS 17021: 2018 containing up to 20% ethanol in volume.</p> |

DIMENSIONS (IN METRES)

(in metres)



44116



7

DIMENSIONS (IN METRES)

(*) **unladen - without roof bar**

(**) **unladen - with roof bar**

WEIGHTS (IN KG)

| | |
|---|-----------------|
| The weights indicated for a basic vehicle without options : they vary depending on your vehicle's equipment. Consult your approved Dealer. | |
| Minimum Weight - Unladen condition (Depending on vehicle) | 905 Kg |
| Maximum Weight - Unladen condition (Depending on vehicle) | 951 Kg |
| Maximum Weight - Laden condition (Depending on vehicle) | 1526 Kg |
| Maximum permissible load on roof (with carrying device) | 50 kg (maximum) |

REPLACEMENT PARTS AND REPAIRS

Original parts are based on strict specifications and are subject to highly specialized tests. Therefore, they are of at least the same level of quality as the parts fitted originally.

If you fit genuine replacement parts always to your vehicle, it will perform well. Furthermore, repairs carried out within manufacturers network using original parts are guaranteed according to the conditions set out on the reverse of repair order.

SERVICE SHEETS

VIN:

| | | | |
|---|-------------|-----------------|------------------------|
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |

* See specific page

SERVICE SHEETS

VIN:

| | | | |
|---|-------------|-----------------|------------------------|
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |

* See specific page

SERVICE SHEETS

VIN:

| | | | |
|---|-------------|-----------------|------------------------|
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |

* See specific page

SERVICE SHEETS

VIN:

| | | | |
|---|-------------|-----------------|------------------------|
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |

* See specific page

SERVICE SHEETS

VIN:

| | | | |
|---|-------------|-----------------|------------------------|
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |

* See specific page

SERVICE SHEETS

VIN:



| | | | |
|---|-------------|-----------------|------------------------|
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |
| | | | |
| Date: | Miles (km): | Invoice number: | Comments/miscellaneous |
| Type of operation: Service <input type="checkbox"/> <input type="checkbox"/> | | Stamp | |
| Anticorrosion check: OK <input type="checkbox"/> Not OK* <input type="checkbox"/> | | | |

* See specific page

ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



VIN:

| | | |
|---|--|--------------|
| Date of repair: |  | Stamp |
| Corrosion repair operation to be carried out: | | |
| Date of repair: |  | Stamp |
| Repair to be carried out: | | |

ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



VIN:

| | | |
|---|--|--------------|
| Date of repair: |  | Stamp |
| Corrosion repair operation to be carried out: | | |
| Date of repair: |  | Stamp |
| Repair to be carried out: | | |

ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



VIN:

| | | |
|---|--|--------------|
| Date of repair: |  | Stamp |
| Corrosion repair operation to be carried out: | | |
| Date of repair: |  | Stamp |
| Repair to be carried out: | | |

ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.



VIN:

| | | |
|---|--|--------------|
| Date of repair: |  | Stamp |
| Corrosion repair operation to be carried out: | | |
| Date of repair: |  | Stamp |
| Repair to be carried out: | | |

ANTICORROSION CHECK

If the continuation of the warranty is subject to repair, it is indicated below.

VIN:

| | | |
|---|--|--------------|
| Date of repair: |  | Stamp |
| Corrosion repair operation to be carried out: | | |
| Date of repair: |  | Stamp |
| Repair to be carried out: | | |

RENAULT NEW VEHICLE WARRANTY

Terms & Conditions

INDIA

1. Warning:

Your RENAULT vehicle is manufactured to meet the regulations and environmental requirements of the country where such RENAULT vehicle is originally sold. In case you relocate it to another country, it may be very difficult to make modifications to comply with the regulations and environmental requirements of that country and it may be difficult to perform repair service in that country. Please note that a RENAULT vehicle relocated to another country is not covered by the warranty.

2. The RENAULT New Vehicle Warranty

2.1 Duration of Manufacturer's New Vehicle Warranty:

Vehicles in the Renault range, delivered as new from 1 January 2025 to the Customer by the authorised RENAULT DEALER, are warranted against any material, assembly or manufacturing defects by the Manufacturer New Vehicle Warranty for a duration of 3 years or 1,00,000 kilometers (whichever is earlier), as per the delivery date.

2.2 Geographical coverage:

2.2.1 This warranty covers any new vehicle sold within geographical boundaries of INDIA

2.2.2 If the vehicle is to be driven and, more importantly, registered outside the geographical area defined above, such vehicle will not be covered under the current warranty as stated herein.

3. Field of application:

3.1 The Customer is covered for:

free repair (parts, consumables and labour) of any material or assembly defect duly found in the vehicle, at their own request, as well as any repairs on damage caused by this defect to other vehicle parts. It is the authorised RENAULT Dealer's discretion to decide whether it is appropriate to repair or replace the defective part, whilst keeping the Customer informed,

3.2 **24/7 assistance** services as defined in the "Renault Assistance" section under clause 6.

3.3 Original equipment Batteries, Tyres and Audio systems are warranted directly by the respective manufacturers. However, authorised RENAULT dealers shall provide assistance for dealing with the defects to the respective manufacturer.

4. The RENAULT New Vehicle Warranty does not cover and Renault India Private Limited (RIPL) and / or RENAULT authorised workshop shall not be responsible for the following:

RENAULT NEW VEHICLE WARRANTY

4.1 Normal maintenance services other than the three free services, including without limitation, cleaning and polishing, minor adjustments, engine tuning, oil/fluid changes, filters replenishment, fastener retightening, wheel balancing, wheel alignment and tyre rotation etc.

4.2 The indirect and remote consequences of any fault (loss of operation, duration of immobilization, etc.);

4.3 Vehicle components which have undergone conversion work, and/or specification and design changes and the consequences (deterioration, premature wear and tear, alterations, etc.) of the conversion work on other vehicle parts or components, or on its specifications;

4.4 The costs incurred by the Customer for routine maintenance

4.5 Replacement of parts due to normal wear and tear resulting from use of the vehicle or from its mileage including but not limited to clutch, shock absorbers, windshield, wiper blades, brake drum, brake disk, brake pads, brake shoe, lamp, plugs, belts, linings, bulbs, fuses, parts made of rubber, etc.

4.6 Damage or failure resulting due to the following causes:

4.6.1 Poor vehicle maintenance, in particular if the instructions for the treatment, the frequency of maintenance or care to be applied to the vehicle set out in the Owner's Manual have not been observed;

4.6.2 Due to lack of use / operation of vehicle over prolonged period[s];

4.6.3 Misuse, abuse, negligence, improper driving habits, theft etc. of the vehicle;

4.6.4 Damage from stress, like use of vehicles in races, rallies, etc.,

4.6.5 Use of parts other than Renault Genuine Parts.

4.6.6 Any device and/or accessories not supplied by RIPL.

4.6.7 Modifications, alterations, tampering or improper repair.

4.6.8 Parts used in applications of which they were not designed or not approved by RIPL.

4.6.9 Slight irregularities not recognized as affecting quality or function of the vehicle or parts, such as slight noise or vibrations, or items considered characteristic of the vehicle.

4.7 Damage caused by the following external causes:

4.7.1 Accidents, impacts, scratches, scoring, projection of gravel or solid bodies, hail, acts of vandalism;

4.7.2 Failure to observe the Manufacturer recommendations;

4.7.3 Deposits due to atmospheric pollution, plant-based deposits such as resin, animal-based deposits such as bird droppings, chemical deposits;

RENAULT NEW VEHICLE WARRANTY

4.7.4 Transportation of the vehicle

4.7.5 Using an adulterated/ incorrect fuel;

4.7.6 Fitting accessories not approved by the Manufacturer;

4.7.7 Fitting accessories approved by the Manufacturer, but installed without observing the recommendations defined by the Manufacturer;

4.7.8 Damage due to airborne fallout, industrial fall out, acid rain, hail and wind storms, or other force majeure events like lightning, fire, floods, earthquakes, war, riots, attacks etc.;

4.7.9 Damage caused due to hydro-static lock.

4.7.10 Paint scratches, dents or similar paint or body damage.

4.8 Incidental or consequential damages , including without limitation, loss of time, inconvenience, loss of use of vehicles or commercial loss

5. How does the RENAULT new vehicle warranty work?

5.1 To be eligible for the RENAULT New Vehicle Warranty, the Customer must:

5.1.1 Check that the delivery document does contain the delivery date of the vehicle - their warranty entitlement is dependent on this;

5.1.2 contact any member of the authorised RENAULT workshop – only such members have authorisation for operations of this sort;

5.1.3 show the duly completed Owner's Manual, as proof of entitlement to the warranty and that the maintenance operations recommended by the Manufacturer have been carried out;

5.1.4 have the defect covered by the RENAULT New Vehicle Warranty confirmed as soon as possible, by a Renault authorised workshop in writing. If the vehicle is un-roadworthy, the Customer must contact the nearest RENAULT authorised workshop member or **Renault Assistance**.

5.2 The RENAULT New Vehicle Warranty does not apply, and RIPL and RENAULT authorised dealer members are exempt from all liabilities, if:

5.2.1 The vehicle has been driven under conditions not in accordance with those stated in the Owner's Manual (example: vehicle overloaded or taking part in any type of sports competition, etc.);

5.2.2 The defect observed is due to the Customer having had the vehicle repaired or serviced in a workshop outside the RENAULT authorized network and not observing the manufacturer's recommendations on the subject.

RENAULT NEW VEHICLE WARRANTY

5.3 By way of consideration for the parts supplied by RIPL under the RENAULT New Vehicle Warranty, parts replaced under this warranty legally become the property of RIPL.

5.4 All operations, parts and labour, carried out under the RENAULT New Vehicle Warranty are guaranteed until the new vehicle warranty expires.

5.5 Transferring ownership of the vehicle does not alter the application conditions of the RENAULT New Vehicle Warranty.

6. RENAULT Assistance.

6.1 Renault Assistance:

Renault Assistance is a special assistance program provided by RIPL to the Customers, who have purchased Renault vehicles.

6.2 Eligible parties:

The Customer, or the authorised driver, and all passengers accompanying this driver (limited in number to the number of vehicle seats stated on the certificate of vehicle registration) will be eligible for assistance under the conditions defined below.

6.3 Intervening cause:

The vehicle is immobilized by a breakdown resulting from an unforeseen mechanical, electrical or electronic fault, covered by the Manufacturer's New Vehicle Warranty.

6.4 Assistance service provider

6.4.1 The Assistance services are exclusively provided by **Renault Assistance**.

6.4.2 RIPL and Renault authorized dealers shall not be liable to reimburse the Customer for the expenses/ cost of repair or replacement of any parts or any labour charges or any other expenses incidental or ancillary thereto, if the Customer does not avail these services of Renault Assistance as detailed herein.

6.4.3 Before calling Renault Assistance, the Customer should make a note of the following information so that the breakdown can be dealt with as efficiently as possible:

6.4.3.1 Precise location of the breakdown:

Precise location of the breakdown: road and number, motorway and milepost, visible landmarks, etc.

6.4.3.2 Vehicle identification:

identification number - refer to sticker located on rear left side door quarter glass or stated in the Owner's Manual, vehicle registration number, engine type.

RENAULT NEW VEHICLE WARRANTY

6.4.3.3 Telephone number

on which the Customer can be reached.

6.4.4 On receiving the call from the Customer, and depending on the circumstances, **Renault Assistance** shall arrange and cover the costs of the services defined below:

6.4.4.1 The Customer will not be liable to pay any costs in advance, excluding any costs for connecting journeys and, taking into account current regulations, any towing costs in the event that the vehicle is towed on a motorway or similar highway. In this case, the Customer must advise **Renault Assistance** as soon as they exit the motorway or similar highway.

6.5 WARNING:

Renault Assistance will not be liable for any costs accrued by the Customer without prior written consent from Renault.

6.6 Roadside repair:

Where possible, Renault Assistance shall repair the vehicle at the roadside as soon as possible. If the vehicle cannot be repaired at the roadside and the vehicle must be towed, the driver and their passengers, as defined in the "Eligible parties" section, will be eligible for the following services.

6.6.1 Towing:

The vehicle will be towed to the nearest RENAULT authorized workshop, or failing that, to the nearest garage where the repair can be carried out.

6.6.2 Cab Assistance:

If customer vehicle is recovered to a dealer by Renault Assistance, the driver and passengers will be provided with one free cab ride, only up to 50 Kms., from the breakdown location, to facilitate them to continue their onward journey. Cost of travel beyond 50 Kms., from the breakdown location, and for any other expenses incurred by the Customer, shall be paid by the Customer and RIPL shall not be responsible or liable for it.

6.7 Renault assistance will be available in India except the following geographical areas, Arunachal Pradesh, Meghalaya, Manipur, Mizoram, Nagaland, Sikkim, Tripura, J&K, Andaman & Nicobar Islands and Lakshadweep.

7. The RENAULT Anticorrosion Warranty

7.1 Duration of the Anticorrosion Warranty:

This warranty will apply from the delivery date for a period of 3 years or 1,00,000 kilometers (whichever is earlier), for vehicles in the Renault range.

7.2 Geographical coverage:

RENAULT NEW VEHICLE WARRANTY

The geographical coverage of the Anticorrosion Warranty is identical to that for the Renault New Vehicle Warranty

7.3 Anticorrosion warranty field of application:

7.3.1 In addition to the RENAULT New Vehicle Warranty, RENAULT guarantees the bodywork and sub frame of all RENAULT vehicles in the Schedule I from perforation from the interior, due to steel panel corrosion caused by a manufacturing, material or protective product application defect.

7.3.2 This guarantee covers the repair or replacement of components with perforated steel panel work due to a manufacturing, material or protective product application defect, acknowledged by the Manufacturer.

7.3.3 It is authorized RENAULT workshop's discretion to decide whether it is appropriate to repair or replace these components, and to inform the Customer.

7.4 The Renault Anticorrosion Warranty does not cover:

7.4.1 Any damage which is not covered by the RENAULT New Vehicle Warranty, as defined at the start of this booklet;

7.4.2 Mechanical components which are not an integral part of the bodywork or sub-frame (wheel rims, exhaust system, etc.).

7.5 Anticorrosion Warranty conditions of application

7.5.1 To obtain the Anticorrosion Warranty, the Customer must contact any member of the RENAULT authorized workshop network - only such members have authorization for operations of this sort.

7.5.2 The customer shall show the duly completed delivery documents as proof of their warranty entitlement.

7.5.3 Application of the RENAULT Anticorrosion Warranty is subject to the anticorrosion tests on the bodywork and sub-frame. Customer shall ensure that these tests are conducted at the mileage intervals stated in the Owner's Manual and at least once in every two years. Scheduled maintenance services in the RENAULT authorized workshop network incorporate these tests.

7.5.4 If the Customer requests to have the anticorrosion test conducted independently of the scheduled maintenance service, the same will be carried out at extra cost to the Customer.

7.5.5 During these tests the Customer shall make sure that the professional carrying out the operation correctly completes the bodywork and sub frame test coupon, in order to validate the continuation of the Anticorrosion Warranty.

7.5.6 Repairs on any deterioration must be made as soon as possible.

7.5.7 The application of the RENAULT Anticorrosion Warranty is also subject to bodywork and subframe repairs being carried out in accordance with RENAULT recommendations.

RENAULT NEW VEHICLE WARRANTY

7.5.8 The repair or replacement of components under the conditions described in the “field of application” (Paragraph 7.3), shall take into account the general condition of the vehicle with regard to its age, mileage and maintenance level.

7.5.9 Parts replaced under the Anticorrosion Warranty legally become the property of RENAULT.

7.5.10 Repairs and components fitted under the Anticorrosion Warranty are guaranteed until the end of the term of the original Anticorrosion Warranty.

7.5.11 Transferring ownership of the vehicle does not alter the application conditions of the Anticorrosion Warranty.

8. The RENAULT Paintwork warranty:

8.1 Duration of the Paintwork Warranty:

RENAULT guarantees the bodywork paintwork and painted parts paintwork (door mirrors, bumpers) for 3 years or 1,00,000 kilometers (whichever is earlier) from the delivery date of the new vehicle, for vehicles in the RENAULT range.

8.2 Geographical coverage:

The geographical coverage of the Paintwork Warranty is identical to that for the RENAULT New Vehicle Warranty.

8.3 Paintwork Warranty field of application:

8.3.1 This warranty covers the free repair or replacement of components with paintwork defects (deterioration of lacquer or finishing varnish, due to any material, manufacturing or application defect) acknowledged by the Manufacturer, with the RENAULT authorized workshop carrying out the operation, keeping the Customer informed.

8.3.2 This repair shall take into account the general condition of the vehicle with regard to its age, mileage and maintenance level.

8.4 The RENAULT Paintwork Warranty does not cover:

8.4.1 any damage which is not covered by The RENAULT New Vehicle Warranty, as defined at the start of this booklet;

8.4.2 damage due to force majeure events: lightning, fire, floods, earthquakes, war, riots and attacks;

8.4.3 Mechanical components which are not an integral part of the bodywork or sub-frame (wheel rims, exhaust system, etc.).

8.4.4 Damage due to action of road elements (sand, gravel, dust or road debris) which results in stone chipping of paint or glass.

8.5 Paintwork Warranty conditions of application

8.5.1 To obtain the Paintwork Warranty, the Customer must contact any member of the RENAULT authorized network - only such members have authorization for operations of this sort.

RENAULT NEW VEHICLE WARRANTY

8.5.2 The customer shall show the duly completed delivery documents as proof of their warranty entitlement.

8.5.3 By way of consideration for the parts supplied by RENAULT under the Paintwork Warranty, parts replaced under this warranty legally become the property of RENAULT.

8.5.4 Repairs and components fitted under the Paintwork Warranty are guaranteed until the end of the term of the original Paintwork Warranty.

8.5.5 Transferring ownership of the vehicle does not alter the application conditions of the Paintwork Warranty.

8.6 This warranty is the entire warranty given by RIPL and no dealer or its or his agent or employee is authorized to extend or enlarge this warranty and no dealer or its or his agent or employee is authorized to make any oral warranty on RIPL's behalf.

8.7 RIPL reserves the right to make any change in design or make any improvement on the vehicle at any time without any obligation to make the same change on vehicles previously sold.

8.8 Warranty service shall be provided only by RIPL's authorized dealers and Dealer Service Branch.

8.9 RIPL's decision is final and binding on the Owner of the vehicle in all warranty matters. RIPL reserves the right for the final decision on all warranty matters.

9. All disputes arising out of this Warranty will be subject to the jurisdiction of Courts in Chennai only.

EXTENDED WARRANTY

8

Renault offers "Renault Secure" Integrated Extended Warranty and Roadside Assistance Program on select models, in addition to the new vehicle warranty. Kindly Contact 1800 315 44 44 (Toll Free number) or your nearest Renault Dealer for more details.

Check for options and prices at <https://www.renault.co.in/renault-services/renault-secure.html>

MAINTENANCE APPENDIX

INFORMATION ON THE MAINTENANCE PROGRAMME

The maintenance program includes the RENAULT service and additional operations. To maintain the original quality of your RENAULT in terms of safety, comfort and performance, you must observe the maintenance program for your vehicle.

RENAULT SERVICE

The RENAULT service applies to all RENAULT vehicles and always includes oil change, oil filter replacement, checks, top-ups and a check of your vehicle's electronic system. The RENAULT service is carried out at the service intervals specified in the maintenance program for your vehicle.

In addition to the service/oil change intervals set by RENAULT, the oil level should still be checked regularly. Your RENAULT dealer is at your disposal to carry out this operation and check other levels, safety parts and for any wear.

ADDITIONAL OPERATIONS:

The additional operations are customized to your vehicle: specific parts or fluids (in addition to the RENAULT service) will need to be replaced in accordance with the service intervals specified in the maintenance program for your vehicle. RENAULT reserves the right to modify its maintenance program at any time during the vehicle's life, within the framework of its vehicle development policy.

CERTAIN CONDITIONS OF USE:

RENAULT recommends that the frequency for replacing specific parts and fluids affected by certain conditions of use should be adapted accordingly.

Hereunder, the list of certain conditions of use and related new replacement frequency (replacement frequency means "when first of the two terms is reached").

A)

- At least 50% of journeys at an average speed less than 30 km/h or with the engine running at idle speed (mainly urban use, taxis, driving school, door-to-door driving, etc),
- At least 30% of kilometers covered towing a trailer weighting more than 500 kg,
- Driving in a dusty environment (building site, more than 1000 km of trails per year,

| Operations | Frequency |
|---|--|
| Change engine oil, oil filter, air filter, fuel filter, cabin filter, belts and rollers (accessory and timing) ^{(1) (2)} | Halve the kilometer frequency for recommended replacement in normal conditions of use, |
| For the following certain condition of use: | |

MAINTENANCE APPENDIX

At least 50% of journeys with the engine running at idle speed, halve, as well, the time frequency replacement for oil and oil filter.

1. The certain condition of use "driving in a dusty environment" does not modify the replacement frequency for belts (accessories and timing) as recommended replacement in normal condition of use.
2. The damper pulleys for certain engines must be replaced during this operation. For more information, please consult your Renault representative.

B)

- Use of engine oil* (for petrol and diesel engines without particles filter), which don't correspond to RENAULT recommendations, (check maintenance pages),
- Prolonged use (+5000 km / year) in temperatures below -15°C,
- Use of fuels that don't correspond to RENAULT recommendations, (See User Manual booklet).
- **For diesel engines with Particles Filter, the use of an other engine oil than the one recommended by RENAULT may damage the Particles Filter.**

| Operations | Frequency |
|-------------------------------|--|
| Change engine oil, oil filter | Halve the kilometer frequency for recommended replacement in normal conditions of use, |

C) Four wheels drive vehicles (4WD): Prolonged use in rough driving conditions (trails, heavy rains...), in very very humid areas or regular driving in water or mud,

| Operations | Frequency |
|---|-------------------------------|
| Change rear axle oil (4WD) Oil specification: TRANSELF UNIVERSAL FE 80W90 | Every other engine oil change |

RADIO FREQUENCY AND LOW FREQUENCY APPROVAL

Any radio frequency or low frequency equipment fitted as standard in the RENAULT range complies with the essential requirements of the R & TTE Directive.

The countries that are covered by or agree to this directive are the countries of the European Union, the French overseas departments and territories, the French Southern and Antarctic lands, the French territorial communities and:

MAINTENANCE APPENDIX

Algeria, Andorra, Azerbaijan, Belarus, Bolivia, Colombia, Costa Rica, Ivory Cost, Cuba, Ecuador, Ethiopia, Georgia, Gautemala, the Republic of Guinea-Bissau, Guyana, Honduras, the Channel Islands, the Cayman islands, the Canary Islands, the Comoros Islands, the Faroe Islands, the United States Virgin Islands, India, Ireland, Liberia, Leichtenstein, Macedonia, Mali, Monaco, Namibia, Nepal, Nicaragua, Niger, Norway, New Zealand, Uganda, Uzbekistan, Panama, Paraguay, Ceuta peninsula, the Czech Republic, Russia, Rwanda, San Marino, El Salvador, Sudan, Switzerland, Tanzania, Thailand, Turkmenistan, Turkey, Ukraine, Vatican City, Vietnam,

SERVICE AND MAINTENANCE

In order to ensure economical and safe vehicle operation and to maintain the value of your vehicle, it is of vital importance that all maintenance work is carried out at the proper intervals as specified. Confirmation of service is recorded in the Owner's Manual. The date and mileage is completed with the stamp and signature of the servicing workshop. Make sure that the Owner's Manual is completed correctly as continuous proof of service is essential.

Maintenance services and record retention are the owner's responsibility. You should retain evidence that proper maintenance has been performed on your vehicle in accordance with the scheduled maintenance services chart.

It is recommended to use engine oil with viscosity grade SAE 15W40.

Service Schedules

| Periodic Maintenance Schedule - PETROL | Time or mileage - Whichever is earlier | | | | | | | | | | | | |
|--|--|-------------------------|--------|--------|--------|--------|--------|--------|--------|--------|---------|---------|---------|
| | Every Km | 1 Year | 2 Year | 3 Year | 4 Year | 5 Year | 6 Year | 7 Year | 8 Year | 9 Year | 10 Year | 11 Year | 12 Year |
| 1st Service | 2,000 | No replacement required | | | | | | | | | | | |
| Engine oil | 10,000 | R | R | R | R | R | R | R | R | R | R | R | R |
| Oil filter | 10,000 | R | R | R | R | R | R | R | R | R | R | R | R |
| Air filter | 10,000 | R | R | R | R | R | R | R | R | R | R | R | R |
| Cabin filter | 10,000 | R | R | R | R | R | R | R | R | R | R | R | R |
| Brake fluid | 60,000 | | | R | | | R | | | R | | | R |

SERVICE AND MAINTENANCE

| Periodic Maintenance Schedule - PETROL | Time or mileage - Whichever is earlier | | | | | | | | | | | | |
|--|--|--------|--------|--------|--------|--------|--------|--------|--------|--------|---------|---------|---------|
| | Every Km | 1 Year | 2 Year | 3 Year | 4 Year | 5 Year | 6 Year | 7 Year | 8 Year | 9 Year | 10 Year | 11 Year | 12 Year |
| Spark plug | 60,000 | | | | | | R | | | | | | R |
| Accessory belts and Rollers | 80,000 | | | | R | | | | R | | | | R |
| Engine Coolant | 80,000 | | | | R | | | | R | | | | R |
| Fuel filter | 1,20,000 | | | | | | | | | | | | R |

SERVICE CHECKS

| THE FOLLOWING CHECKS MUST BE CARRIED OUT DURING EVERY SERVICE | |
|---|--|
| Sl.No. | |
| 1 | Check the wiper blades and screen washer fluid levels |
| 2 | Check the condition of the windscreen and door mirrors |
| 3 | Check the operation of the instrument panel warning lights |
| 4 | Check the exhaust pipe |
| 5 | Check the levels, condition and sealing of the hydraulic power-assisted steering circuit (if fitted) |
| 6 | Check the levels, condition and sealing of the brake/clutch circuit |
| 7 | Check the presence of the wheel valve caps |
| 8 | Check the presence of the airbag and engine compartment labels |
| 9 | Check the signalling and exterior/interior lighting |
| 10 | Check the wear of the brake discs and pads |
| 11 | Check the condition and pressure of the tyres and road wheel security |
| 12 | Check the levels, condition and sealing of the cooling circuit |
| 13 | Check the levels, condition and sealing of the sequential gearbox circuits (if fitted) |
| 14 | Anti-corrosion check |
| 15 | Check the 12 V battery with the test tool |
| 16 | Check the computers with the diagnostic tool |
| 17 | Check the condition and sealing of the gaiters/rubber mountings/ball joints/shock absorbers |
| 18 | Check and lubricate the bonnet lock |
| 19 | Clean the sunroof system (if fitted) |

SERVICE CHECKS

| THE FOLLOWING CHECKS MUST BE CARRIED OUT DURING EVERY SERVICE | |
|---|--|
| 20 | Documentation and positioning of the maintenance label |
| 21 | Drain the water from the fuel filter |
| 22 | Engine oil change alert reinitialisation |

ALPHABETICAL INDEX

Symbols

»hands-free » card : use, 25

A

Accessories socket, 124

Additional methods of restraint to the front seat belts, 41

Advice on antipollution, 94

Air bag, 41

Air conditioning, 115, 116

Air vents, 113

Anti-corrosion protection, 143

Antipollution advice, 90, 94

Ashtrays, 124

B

Battery troubleshooting, 169, 173

Bonnet, 132

C

Card : use, 23, 25

Changing a wheel, 147

Changing gear, 82, 103

Child booster seat, 47

Child restraint/seat, 47

Child safety, 47

Child seats, 47

Cigar lighter, 124

Cleaning : inside the vehicle, 145

Closing the doors, 32

Control instruments, 69

Courtesy light, 119

D

Doors, 32

Doors/tailgate, 23

Driving, 77, 90, 103, 107, 109

E

Electric windows, 117

Emergency key, 23

Emergency spare wheel, 147, 153

Engine oil, 134

Engine oil capacity, 134

Engine oil grade, 134

Environment, 95

F

Filter, 137

Fittings, 121

Front seat adjustment, 35

Front seats, 35

Front seats adjustment, 35

Fuel advice on fuel economy, 90

Fuel economy, 90

Fuel tank, 75

ALPHABETICAL INDEX

G

Gear lever, 82

H

Handbrake, 82

Hands-free telephone integrated control, 130

Heating and air conditioning system, 113, 115, 116

Heating system, 113, 115, 116

I

Interior trim maintenance, 145

K

Keys, 20

L

Levels, 137

Lighting : exterior, 69

Lighting : interior, 119

Lights, 69

Locking the doors, 23, 25

M

Maintenance, 94

Maintenance : bodywork, 143

Maintenance : interior trim, 145

Maintenance : mechanical, 137

Map reading lights, 119

Methods of restraint in addition to the seat belts, 41

Multimedia equipment, 130

N

Navigation, 130

Navigation system, 130

O

Opening the doors, 32

P

Paintwork maintenance, 143

Parking distance control, 107, 109

Practical advice, 173

Pretensioners, 41

Puncture, 147

R

Radio, 130

Rear seat, 125

Remote control door locking unit, 20

Reverse gear selecting, 82, 103

Reversing sensor, 107, 109

S

Seat belt pretensioners front seat belt, 41

Seat belts, 41

ALPHABETICAL INDEX

Sequential gearbox, 103
Signals and lights, 69
Starting, 77
Starting the engine, 77
Steering wheel adjustment, 56
Storage compartment, 121
Storage compartments, 121

T

Tailgate, 128
Telephone, 130
Tool kit, 149
Transporting children, 47
Tyres, 153

V

Ventilation heating and air conditioning system, 115, 116

W

Warning buzzer, 32
Washing, 143
Wheel trim, 149
Windows, 117
Windscreen washer, 72, 137
Wipers, 72





RENAULT S.A.S. SOCIÉTÉ PAR ACTIONS SIMPLIFIÉE / 122-122 BIS, AVENUE DU GÉNÉRAL LECLERC 92100 BOULOGNE-BILLANCOURT R.C.S. NANTERRE 780 129 987 — SIRET 780 129 987 03591 / renaultgroup.com
NU 1321-7 - 99 91 025 49V - 01/2025 - Edition anglaise



999102549V

9S